

PDF Rackshelf LIST

ORGANIZED BY MANUFACTURER,
THIS LIST IS ONLY A ONE-TIME
SAMPLING OF OUR CONSTANTLY
UPDATED LIST.

IF YOU ARE CONNECTED TO THE
INTERNET, USE THE "TO MAP.COM"
BUTTON TO TAKE YOU TO OUR
HOME PAGE. THE RACKSHELF LIST
ON THE SITE IS UPDATED ON A
REGULAR BASIS.

CLICK THE RIGHT ARROW BUTTON TO NAVIGATE
WITH BOOKMARKS...

Manufacturer	Model	Space	FaceOnly	SPL
10 BASE	TMPR	2	N	Y
360 SYSTEMS	DIGICART	4	N	N
360 SYSTEMS	DIGICARTII	4	N	Y
360 SYSTEMS	DIGICARTSIAMES	4	N	Y
3COM	HUB8TPC	2	N	N
3M	2066AA	3	N	N
3M	AT120	4	N	N
A/D/S	4000	8	N	Y
A/D/S	A2	2	Y	N
A/D/S	C3	2	Y	N
A/D/S	C4	2	Y	N
A/D/S	CD3	2	Y	N
A/D/S	CD4	2	Y	N
A/D/S	PH6	4	N	Y
A/D/S	SC4	3	N	N
A/D/S	SC6	3	N	N
ACCOUSTECH	FIDELPAC	4	N	N
ACCOUSTECH	MTR4.5	4	N	N
ACCUTOUCH	P274-144GS	8	N	Y
ACER	33	8	N	Y
ACER	7034T	8	N	Y
ACER	7156E	8	N	Y
ACURUS	100X3	4	N	N
ACURUS	200X3	4	N	N
ACURUS	A150	3	N	N
ACURUS	A200X3	4	N	N
ACURUS	A250	3	N	N
ACURUS	ACT1	3	N	N
ACURUS	RL11	3	N	N
ADC	SS315	3	N	N
ADC	SS33	3	N	N
ADC	VSS2	3	N	N
ADCOM	GCD700	3	N	N
ADCOM	GDA700	2	N	N
ADCOM	GFA2535	4	N	N
ADCOM	GFA5006	4	N	N
ADCOM	GFA5200	3	N	N
ADCOM	GFA5300	3	N	N
ADCOM	GFA535	3	N	N
ADCOM	GFA5400	4	N	N
ADCOM	GFA545	4	N	N
ADCOM	GFA545II	4	N	N
ADCOM	GFA5500	5	N	N
ADCOM	GFA555	5	N	N
ADCOM	GFA555II	5	N	N
ADCOM	GFA565	5	N	N
ADCOM	GFA5800	6	N	N
ADCOM	GFA585	6	N	N
ADCOM	GFA585	3	N	N
ADCOM	GFA6000	4	N	N

ADCOM	GFP555 II	3	N	N
ADCOM	GFP565	3	N	N
ADCOM	GFS3	3	N	N
ADCOM	GFS4	3	N	N
ADCOM	GFS6	3	N	N
ADCOM	GFT555II	3	N	N
ADCOM	GSP560	4	N	N
ADCOM	GTP350	3	N	N
ADCOM	GTP400	3	N	N
ADCOM	GTP450	3	N	N
ADCOM	GTP500	3	N	N
ADCOM	GTP600	3	N	N
AID	RX2000B	3	N	Y
AIWA	ADR30	3	N	N
AIWA	ADR40	4	N	N
AIWA	ADR707	4	N	N
AIWA	ADS15	3	N	N
AIWA	ADWX717	4	N	N
AIWA	ADWX727	4	N	N
AIWA	ADWX808	4	N	N
AIWA	ADWX888	4	N	N
AIWA	ADWX909	4	N	N
AIWA	APR30	3	N	N
AIWA	CXN5200D	7	N	Y
AIWA	DXM55	3	N	N
AIWA	F990	3	N	N
AIWA	HVM110SU	3	N	N
AIWA	HVMX1	3	N	Y
AIWA	HVMX100	3	N	N
AIWA	HVMX1SHR	3	N	Y
AIWA	MDR530	2	N	N
AIWA	R450	3	N	N
AIWA	WX220	3	N	N
AIWA	XD001	3	N	N
AIWA	XDS260	3	N	N
AKAI	GX9	3	N	N
AKAI	GXF90	3	N	N
AKAI	GXR60	3	N	N
AKAI	GXR60EX	3	N	N
AKAI	GXR70	3	N	Y
AKAI	HXR44	3	N	N
AKAI	HXR5	3	N	N
AKAI	SSV20	3	N	N
AKAI	VSX475EGN	3	N	Y
AKAI	VSX560EGN	3	N	N
AKAI	VSX600	3	N	Y
ALPHASTAR	DV3	2	N	N
ALTA	PYXIS	3	N	N
ALTINEX	CAPTAIN	3	N	Y
ALTINEX	TR6102HD	2	N	Y
AMC	2445	3	N	N
AMC	AV81HT	3	N	N

AMC	T7	3	N	N
AMDEK	AM432LC	8	N	Y
AMDEK	COLOR1+	9	N	N
AMDEK	VIDEO310A	7	N	Y
AMERICAN MICRO SYS	MICRO SCANNER	2	N	Y
AMERITECH	3104101	2	N	N
AMPEX	ADO2000	7	N	N
AMX	AXBTMX	2	N	Y
AMX	AXBVOL3	2	N	Y
AMX	AXULC	4	N	Y
AMX	MUSIC CENTER	5	N	N
AMX	PLB-HUB	4	N	N
AMX	PLBAMP8	4	N	N
AMX	PLBAS8	4	N	N
AMX	PLBCF10	4	N	N
AMX	PLKDMS(FACE ONLY)	3	N	Y
ANCHOR	AN1000	4	N	Y
ANCHOR	AN1400	4	N	N
ANGSTROM	200	3	N	N
ANSEL	P2508C	2	N	Y
AOC	4V	8	N	Y
API	500B4	4	N	N
APPLE	2SI	3	N	N
APPLE	7300/180	4	N	Y
APPLE	7300/200	4	N	Y
APPLE	7500\100	4	N	N
APPLE	7600/120	4	N	Y
APPLE	CDSCPLUS	3	N	N
APPLE	IICX	4	N	N
APPLE	M2943	8	N	Y
APPLE	PM7100	4	N	Y
APPLE	QUADRA605	2	N	N
APPLE	QUADRA630	3	N	N
APPLE	QUADRA650	4	N	N
APPLE	QUADRA950	11	N	Y
APPLE	RGB	7	N	N
APT CORP.	NSRW06	3	N	N
ARCAM	ALPHA 8	3	N	N
ARCAM	DELTA70	3	N	N
ARCHER	152100	2	N	N
AROGON	8008	4	N	N
ASCEND	MBVBRI4U	2	N	N
AST	BRAVO MST5133	9	N	Y
ASTRO PRO	Z500	3	N	N
AT&T	2A1	2	N	Y
AT&T	DATAPHONE2	2	N	N
ATARI	1050	3	N	N
ATEN	CS106	3	N	Y
ATLANTIC TECH.	200D	2	N	N
ATUS	WR5	2	N	N
ATV	QSP860MPX	2	N	Y
ATX	7BAY	4	N	Y

AUDIO AUTHORITY	515	2	N	N
AUDIO CONTROL	1250	4	Y	Y
AUDIO CONTROL	BIJOU	3	N	N
AUDIO CONTROL	C101	3	N	N
AUDIO CONTROL	OCTIVE	2	N	N
AUDIO CONTROL	PHASE COUPLER	2	N	N
AUDIO CONTROL	RICHTERSCALES	2	N	N
AUDIO CONTROL	TEN SERIES III	3	N	N
AUDIO CONTROL	TENSERIESTWO	3	N	N
AUDIO CONTROL	THE RIALTO	2	N	N
AUDIO DYNAMICS	CA2000A	3	N	N
AUDIO DYNAMICS	CA2000E	3	N	N
AUDIO DYNAMICS	CD2000E	2	N	N
AUDIO DYNAMICS	T2000E	2	N	N
AUDIO EASE	310728	3	N	N
AUDIO EASE	MONACOCC16A	7	N	N
AUDIO EASE	MONICO SC AUDIO	4	N	N
AUDIO EASE	MONICO SC SC COMPUTER	3	N	Y
AUDIO EASE	SP1CONTROLCNT	5	N	N
AUDIO EASE	SP1POWERCNT.	3	N	N
AUDIO EASE	SP2	7	N	N
AUDIO EASE	VS16	5	N	N
AUDIO TECH	HD100	2	N	Y
AUDIO TECHNICA	ATCD10	3	N	N
AUDIOACCESS	KPS	2	N	Y
AUDIOACCESS	MRX	4	N	N
AUDIOACCESS	PX240	5	N	N
AUDIOACCESS	PX4	2	N	N
AUDIOACCESS	PX6	2	N	N
AUDIOACCESS	PX600	3	Y	N
AUDIOACCESS	PX603	3	Y	N
AUDIOACCESS	PX612	3	Y	N
AUDIONICS	SD2	2	N	Y
AUDIOSOURCE	AMP3	3	N	N
AUDIOSOURCE	AMPONE	2	N	N
AUDITEL	PMIC2B	3	N	N
AVL	CX120	2	N	N
AVL	SUPERX15	2	N	N
AXXIS	CM17GS	9	N	Y
AXXIS	SP1440	9	N	Y
AZZ	486	8	N	Y
B & W	CASA	3	N	N
B+K	1823	2	N	N
B+K	AMP2000	3	N	N
B+K	AV6000	4	N	N
B+K	AVP2000	3	N	N
B+K	AVP2030	3	N	N
B+K	AVR202	4	N	N
B+K	DT1	2	N	Y
B+K	EX4420	4	N	N
B+K	REFERENCE20	3	N	N
B+K	ST3030	4	N	N

B+K	VIDEO5	4	N	Y
BANG OLUFSEN	5000	2	N	N
BANG OLUFSEN	BEOCORD5000	2	N	N
BANG OLUFSEN	BEOCORD6500	2	N	N
BANG OLUFSEN	BEOGRAMCD50	2	N	Y
BANG OLUFSEN	BEOMASTER6500	2	N	Y
BANG OLUFSEN	CMM10	3	N	N
BELKIN	F1D064	2	N	N
BENJAMIN	ACC15	3	N	N
BERNOULLI	230	2	N	Y
BERNOULLI	TRANSPORTABLE	2	N	Y
BLACKBOX	ABCSWITCH	3	N	N
BLACKBOX	MODEM325	2	N	Y
BLACKBOX	SCSI	2	N	Y
BLACKBOX	SERVSWITCH	2	N	N
BMB	CD-100A	7	N	N
BMB	CD-100M	4	N	N
BOGEN	BPA60	3	N	N
BOGEN	CP1	2	N	N
BOGEN	CTS1100	3	N	Y
BOSE	102	4	N	Y
BOSE	901SERIESVI	2	N	N
BOSE	BMA125	4	N	N
BOSTON ACCOUSTICS	CENTER STAT 7	4	N	N
BRAHLER	M741	3	N	N
BRYSTON	4WAYSWITCH	2	N	N
BSR	3000EQ	3	N	N
BSR	EQ3000	3	N	N
BURLE	TC1909	5	N	N
BURLE	TC1917	8	N	N
BURLE	TC210A	6	N	N
BURLE	TC215	8	N	N
C PHONE	CP10L	3	N	N
CABLE BOX	CRX50003M	2	N	N
CABLETECH	CABLEBOX	2	N	N
CALAWAY ENG.	MK1	4	N	N
CALAWAY ENG.	T1418	7	N	N
CALI. AUDIO LAB	ALPHA	3	N	N
CALI. AUDIO LAB	CL10	3	N	N
CALI. AUDIO LAB	DELTA	3	N	N
CALI. AUDIO LAB	ICONMK2	3	Y	N
CANON	MS10	2	N	N
CANON	RV301	2	N	N
CANON	SP10	3	N	N
CANON	VRHF600	3	N	N
CANON	VRHF710	3	N	N
CANTON	PLUS D	5	N	Y
CANTON	PLUSC1X	9	N	N
CANTON	SPEAKER	5	N	Y
CARDINAL	MB2400EX	2	N	N
CARVER	AV405	3	N	N
CARVER	AV64	3	N	N

CARVER	AV705X	4	N	N
CARVER	AV806X	4	N	N
CARVER	C15v	3	N	N
CARVER	C2	2	N	Y
CARVER	CMV1185	4	N	N
CARVER	CT17	3	N	N
CARVER	CT23	3	N	N
CARVER	CT24	3	N	N
CARVER	CT27v	3	N	N
CARVER	CT29V	3	N	N
CARVER	LOUDSPK.CONT.SY	2	N	Y
CARVER	MDV500	4	N	N
CARVER	SDA350	4	N	N
CARVER	SDA360	3	N	N
CARVER	SDA370	3	N	N
CARVER	SDA390	3	N	N
CARVER	SDA490T	3	Y	N
CARVER	TDR1500	4	N	N
CARVER	TDR1550	3	Y	N
CARVER	TFM35x	3	N	N
CARVER	TFM55X	3	N	N
CARVER	TFM6CB	2	N	N
CARVER	TX12	2	N	N
CARVER	TX2	2	N	Y
CARVER	TX8	2	N	N
CD SOLUTIONS	1451	9	N	Y
CD SOLUTIONS	CD 1401	8	N	Y
CELESTION	6000	2	N	N
CENTERPIONT TECH	CTS8055CS	2	N	Y
CETEC VEGA	PROWIRELESS	2	N	N
CETEC VEGA	R42	3	N	N
CHANNEL +	D2VHP	2	N	Y
CHANNEL VISION	CVT3UB	2	N	N
CHAPARRAL	MONTEREY100C	3	Y	N
CHAPARRAL	MONTEREY50	3	Y	N
CHAPARRAL	MONTEREY90	3	N	N
CHAPARRAL	MONTERY 55	3	Y	Y
CHAPARRAL	SIERRA111	3	N	N
CHIRO	C200	4	N	N
CHIRO	C300	4	N	N
CHIRO	C5.1	2	N	N
CHIRO	C500	6	N	N
CHIRO	C800	4	N	N
CHROMASCOPE	VIDENHAN.	2	N	N
CHROMASCOPE	WIDEVIDENH	4	N	N
CIMARRON	C MARK III	3	N	Y
CINEPRO	600X2	4	Y	N
CISCO SYSTEMS	2501	2	Y	N
CITATION	SEE HARMON KARDON	2	N	
CLEAR COM	AB100	2	N	Y
CLI	SPECTRUM SAVER	2	N	N
COFFIN	1M DUAL	4	N	N

COFFIN	1M SINGLE	4	N	N
COLLINS	32S75S	5	N	Y
COLORADO	250mb	9	N	Y
COMPAQ	150	8	N	Y
COMPAQ	DESK PRO4000	11	N	Y
COMPAQ	XE560	3	N	Y
COMPUTER	CASE	5	N	Y
COMSTREAM	DR200	3	N	Y
CONRAC	2620C9	6	N	N
COUNTERPOINT	1AM	4	N	Y
CRAIG	PT628	3	N	Y
CRAY	DCP3083	2	N	N
CREEK	T43	2	N	N
CRESTRON	CTP3000DSTB	5	N	N
CRESTRON	LC3000L	5	N	N
CRESTRON	ST-CP	2	N	N
CRESTRON	ST-CS	2	N	N
CRESTRON	ST1500C(FACE ONLY)	4	N	N
CROWN	IC150	4	N	N
CTX	1451ES	8	N	Y
CTX	1562CLR	8	N	Y
CURRENT DESIGN	PC8PLUS	3	N	N
CYBERVISION	C50	8	N	Y
DAEWOO	CMC1427X1	8	N	Y
DAHLQUIST	DQLP1	2	N	N
DAIICHI KOSHO	DKK200P	3	N	N
DAIWA	CN103	2	N	Y
DATA PRECISION	2590	2	N	N
DATA SWITCH	A/B SWITCH	2	N	Y
DATA SWITCH	HDD15152V	2	N	N
DATA XFER SWITCH	A/B SWITCH	2	N	Y
DATA XFER SWITCH	A/B/C/D SWITCH	2	N	Y
DATACAP	COMSWITCH	3	N	N
DATATON	AC PAX	2	N	Y
DATATON	SMART PAX	2	N	Y
DAVIS	DT100	2	N	N
DBX	1020	3	N	N
DBX	1BXIII	2	N	N
DBX	200	2	N	N
DBX	2020	4	N	N
DBX	DX3	3	N	N
DBX	DX5	3	N	N
DBX	RDC21	3	N	N
DELL	D1528LS	8	N	Y
DELL	D825HT	9	N	Y
DELL	D825TM	8	N	Y
DELL	OPTIPLEX GXPRO	4	N	N
DELL	P100T	4	N	Y
DELL	XM575	4	N	Y
DENON	AVC2000	4	N	N
DENON	AVC3000	4	N	N
DENON	AVC3020	4	N	N

DENON	AVC3030	5	N	N
DENON	AVC700	4	N	N
DENON	AVP5000	4	N	Y
DENON	AVP8000	4	N	Y
DENON	AVR1010	4	N	N
DENON	AVR1200	4	N	N
DENON	AVR1500	4	N	N
DENON	AVR2000	4	N	N
DENON	AVR2400	4	N	N
DENON	AVR2500	4	N	N
DENON	AVR2600	4	N	N
DENON	AVR2700	4	N	N
DENON	AVR3000	5	N	N
DENON	AVR3200	4	N	N
DENON	AVR3600	5	N	Y
DENON	AVR5600	5	N	Y
DENON	AVR810	4	N	N
DENON	AVR900	4	N	N
DENON	DA500	2	N	N
DENON	DAP2500	4	N	N
DENON	DCD1500	3	N	N
DENON	DCD1520	4	N	N
DENON	DCD2700	3	N	N
DENON	DCD3300	3	N	N
DENON	DCD3520	4	N	N
DENON	DCD425	3	N	N
DENON	DCD590	3	N	N
DENON	DCD615	3	N	N
DENON	DCD620	3	N	N
DENON	DCD660	3	N	N
DENON	DCD695	3	N	N
DENON	DCD700	3	N	N
DENON	DCD815	3	N	N
DENON	DCD860	3	N	N
DENON	DCDS10	4	N	Y
DENON	DCM260	3	N	N
DENON	DCM320	3	N	N
DENON	DCM340	3	N	N
DENON	DCM360	3	N	N
DENON	DCM420	3	N	N
DENON	DCM440	3	N	N
DENON	DCM444	3	N	N
DENON	DCM450	3	N	N
DENON	DCM460	3	N	N
DENON	DCM520	3	N	N
DENON	DCM550	3	N	N
DENON	DCM555	3	N	N
DENON	DCM555II	3	N	N
DENON	DCM560	3	N	N
DENON	DCM777	3	N	N
DENON	DE70	4	N	N
DENON	DN1200CCNTRL	3	N	N

DENON	DN1200FCHNG.	6	N	N
DENON	DN1400F	6	N	N
DENON	DN950FA	4	N	N
DENON	DN951FASINGL	4	N	N
DENON	DN951FATRIPLE	4	N	
DENON	DN961FASINGLE	4	N	N
DENON	DN961FATRIPLE	4	N	N
DENON	DN970FA	4	N	N
DENON	DN980F	4	N	N
DENON	DN990R	4	N	N
DENON	DN990RDUAL	4	N	Y
DENON	DN990RTRIPLE	4	N	N
DENON	DN995R	4	N	N
DENON	DRA1035R	4	N	N
DENON	DRA335R	3	N	N
DENON	DRA365	3	N	N
DENON	DRA375RD	4	N	N
DENON	DRA545R	4	N	N
DENON	DRA565RD	4	N	N
DENON	DRA635R	4	N	N
DENON	DRA755	3	N	N
DENON	DRA775RD	4	N	N
DENON	DRA825RA	4	N	N
DENON	DRA835R	4	N	N
DENON	DRA95VR	4	N	N
DENON	DRM07	3	N	N
DENON	DRM10	3	N	N
DENON	DRM10HR	3	N	N
DENON	DRM11	3	N	N
DENON	DRM20	3	N	N
DENON	DRM24HX	3	N	N
DENON	DRM400	3	N	N
DENON	DRM44	3	N	N
DENON	DRM500	3	N	N
DENON	DRM510	3	N	N
DENON	DRM550	4	N	N
DENON	DRM700	4	N	N
DENON	DRM710	3	N	N
DENON	DRR680	3	N	N
DENON	DRR730	3	N	N
DENON	DRR780	3	N	N
DENON	DRS640	3	N	N
DENON	DRS810	3	N	N
DENON	DRW580	4	N	N
DENON	DRW585	4	N	N
DENON	DRW660	3	N	N
DENON	DRW830	3	N	N
DENON	DRW840	3	N	N
DENON	DRW850	4	N	N
DENON	DTR2000	3	N	N
DENON	DVD2000	3	N	N
DENON	DVD3000	3	N	N

DENON	DVD5000	4	N	Y
DENON	LA2000	3	N	N
DENON	LA2100	4	N	N
DENON	LA2300	4	N	N
DENON	LA2500	4	N	N
DENON	LA3000	3	N	N
DENON	LA3100	4	N	N
DENON	LA3500	4	N	N
DENON	PMA560	4	N	N
DENON	PMA700V	4	N	N
DENON	PMA737	3	N	N
DENON	PMA915R	4	N	N
DENON	POA2400A	5	N	N
DENON	POA2800	4	N	N
DENON	POA2800	5	N	N
DENON	POA800	3	N	N
DENON	POA8200	4	N	Y
DENON	POA8300	4	N	Y
DENON	PRA1100	3	N	Y
DENON	PRA1200	3	N	Y
DENON	PRA1500	3	N	N
DENON	PRAS10	4	N	Y
DENON	TU1500RD	2	N	Y
DENON	TU280	2	N	N
DENON	TU380RD	2	N	N
DENON	TU400	2	N	N
DENON	TU450	2	N	N
DENON	TU460	2	N	N
DENON	TU550	2	N	N
DENON	TU650	2	N	N
DENON	TU660	2	N	N
DENON	TU680NAB	2	N	N
DENON	TU800	3	N	N
DIGI	CCON16	3	N	Y
DIGI	CCON16RJ45	2	N	N
DIGITAL	466	3	N	Y
DIGITAL	VRT17HA	10	N	Y
DIGITAL AUDIO CORP	MICRODAC2	2	N	N
DIGITAL AUDIO CORP	MICRODAC3	2	N	N
DIGITAL AUDIO CORP	pcap	2	N	N
DIGITAL AUDIO CORP	SPECTRUMANAL.	5	N	Y
DIGITAL BASICS	DIGITAL BASICS	4	N	N
DIGITAL DOMAIN	FCN1	2	N	N
DIGITAL LINK	DL551X30	2	N	N
DIGIVIEW	HR1435	8	N	N
DIGIVIEW	HR1707+	9	N	Y
DISH NETWORK	1000	2	N	N
DISH NETWORK	4500	2	N	N
DISH NETWORK	ISD4000	2	N	N
DORROUGH	40A	2	N	N
DRAKE	ESR1824	3	N	N
DRAKE	R7	4	N	N

DRAKE	R8	4	N	N
DTK	APRI76M	10	N	Y
DTK	CMD1411	8	N	Y
DTK	MA1435	8	N	Y
DTK	MD1435	8	N	Y
DTK	QUIN 55M	11	N	Y
DWIGHT CAVENDISH	VP702	2	N	N
DWIN	LD2	3	N	N
EAZY	ABCDESWITCH	3	N	Y
ECHO STAR	256VM	3	N	N
ECHO STAR	3000	2	N	N
ECHO STAR	5000	2	N	N
ECHO STAR	510	3	N	Y
ECHO STAR	ISD2200	2	N	N
ECHO STAR	ISD2300	2	N	N
ECHO STAR	ISD3000	2	N	N
ECHO STAR	SRD3000	3	N	N
EIBEX	EXSQ143	2	N	N
ELAN	EPLMDM1000	3	N	N
ELAN	HDA1000	4	N	N
ELAN	HDC1000	5	N	N
ELBEX	EXS126	2	N	N
ELECTROHOME	38D051MAU	8	N	Y
ELMO	EC202II	2	N	N
EMERSON	CD150A	3	N	N
EMERSON	VCR4000	3	N	N
EMERSON	VCR765	3	N	N
ENLIGHT. AUD.	ENCORE	3	N	Y
ENLIGHT. AUD.	OVATION THEATRE MASTER	3	N	Y
ENLIGHT. AUD.	SWITCH MASTER	2	N	Y
ENLIGHT. AUD.	T8000	5	N	Y
ENLIGHT. AUD.	THEATER MASTER	3	N	Y
ENLIGHT. AUD.	THEATER MASTER 5.1	3	N	Y
ESCIENT	TUNEBASE 2000I	4	N	Y
ESPIRT	400	8	N	Y
ESPIRT	CK4148	8	N	N
EVER VISION	MN200	8	N	Y
EXTRON	8PLUS	3	N	Y
EXTRON	ANDORA	2	N	N
EXTRON	CD400	2	N	N
EXTRON	EMOTIA	2	N	N
EXTRON	EMOTIA XTREME	2	N	N
EXTRON	EXSW8A	3	N	N
EXTRON	P/2DA2LC	2	N	N
EXTRON	RGB108+	2	N	N
EXTRON	RGB109	2	N	N
EXTRON	RGB120	2	N	Y
EXTRON	RGB202	2	N	N
EXTRON	RGB202+	2	N	N
EXTRON	RGB202xi	2	N	N
EXTRON	RGB300	2	N	N
EXTRON	RGB302	2	N	N

EXTRON	SUPER EMOTIA GX	2	N	N
EXTRON	SW2AR	3	N	Y
EXTRON	SW2VGA	3	N	Y
EXTRON	SW4AR	3	N	Y
EXTRON	SW4ARHV	3	N	Y
EXTRON	SW6AR	3	N	Y
EXTRON	SW6SVMX	2	N	N
EXTRON	SWY	3	N	N
EXTRON	VSC100	2	N	Y
FAROUDJA	DV1000	3	N	Y
FAROUDJA	LD100	3	N	N
FAROUDJA	LD1000	4	N	Y
FAROUDJA	LD200	3	N	Y
FAROUDJA	NLD200	3	N	Y
FAROUDJA	VP100	2	N	N
FAROUDJA	VP250	3	N	Y
FAROUDJA	VP301	3	N	N
FAROUDJA	VP400	3	N	N
FAROUDJA	VP600P+	3	N	N
FIDLIPAC	340	4	N	N
FISHER	AD870	3	N	N
FISHER	CA870	3	N	N
FISHER	CRW56	4	N	N
FISHER	CRW683	4	N	N
FISHER	CRW870	3	N	N
FISHER	EQ870	2	N	N
FISHER	FM870	2	N	N
FISHER	FM9335	2	N	N
FISHER	FVH5550	3	N	N
FISHER	FVH6500	3	N	Y
FOR A	FA800	3	N	N
FOR A	VTW100	6	N	N
FOSGATE	4100	5	N	N
FOSGATE	DSL TWO	3	N	N
FOSGATE	DSM3602	2	N	N
FOSGATE	DSM3606	2	N	N
FOSGATE	DSM3608	2	N	N
FOSGATE	DSM3610	2	N	N
FOSGATE	M60MKII	2	N	N
FOSGATE	MODEL1	3	N	N
FOSGATE	MODEL3PROCESS	3	N	N
FOSGATE	MODEL4	3	N	N
FOSGATE	MODEL5	2	N	N
FOSGATE	MODEL560	3	N	N
FOSTEX	6301	3	N	N
FSR	KVM10	3	N	N
FSR	VSM10	3	N	Y
GATEWAY	2000/BATL	5	N	Y
GATEWAY	DCM	4	N	N
GATEWAY	EV700	9	N	Y
GATEWAY	G6266	4	Y	N
GATEWAY	GS233	11	N	Y

GATEWAY	P55C-166	4	Y	Y
GE	6018	3	N	N
GE	97100	3	N	Y
GE	97115	3	N	N
GE	97176	3	N	N
GE	97785	3	N	N
GE	ADUV3800	3	N	N
GE	CABLEMAX	2	N	N
GE	VG7775	3	N	N
GE	VG7785	3	N	N
GE	VIDMON	9	N	Y
GEMINI	PL9	2	N	N
GENERAL INSTRUMENT	2100E	3	N	N
GENERAL INSTRUMENT	256	3	N	Y
GENERAL INSTRUMENT	2730R	3	N	Y
GENERAL INSTRUMENT	2750R	3	N	Y
GENERAL INSTRUMENT	3501	3	N	N
GENERAL INSTRUMENT	5507	2	N	N
GENERAL INSTRUMENT	6501	3	N	N
GENERAL INSTRUMENT	650I	3	N	N
GENERAL INSTRUMENT	CFT 2200	2	N	N
GENERAL INSTRUMENT	DP5DRXDRZDL4	2	N	N
GENERAL INSTRUMENT	DPBB7322M1	2	N	N
GENERAL INSTRUMENT	DPBB7322R2M1	2	N	N
GENERAL INSTRUMENT	DPBB7512PR2	2	N	N
GENERAL INSTRUMENT	DPV5212R3	2	N	N
GENERAL INSTRUMENT	DPV7212	2	N	N
GENERAL INSTRUMENT	DPV7234	2	N	N
GENERAL INSTRUMENT	DRX3DIC105	2	N	N
GENERAL INSTRUMENT	DRZ3	2	N	Y
GENERAL INSTRUMENT	DSR920	3	N	N
GENERAL INSTRUMENT	GI3501	3	N	N
GENERAL INSTRUMENT	RC550	2	N	N
GENTNEL	GT700	2	Y	N
GO VIDEO	GV10W	3	N	N
GO VIDEO	GV6060	5	N	Y
GO VIDEO	GV8020	3	N	Y
GOLDSTAR	1410+	8	N	Y
GOLDSTAR	1460DL	8	N	Y
GOLDSTAR	1465DLS	9	N	Y
GOLDSTAR	1520	8	N	Y
GOLDSTAR	1527	8	N	Y
GOLDSTAR	GHV1280M	3	N	N
GOLDSTAR	LG486	4	N	Y
GTE	SPACENET	2	N	N
GYR	TLC1800	4	N	N
GYR	TLC2196HD	3	N	Y
GYR	TLC2400	4	N	N
HAFLER	110A	2	N	N
HAFLER	330	2	N	N
HAFLER	DH101	3	N	N
HAFLER	DH220	2	N	N

HAFLER	SERIES9130	3	N	N
HARMON KARDON	1.5	5	N	N
HARMON KARDON	2.0	3	N	N
HARMON KARDON	ADP303	3	Y	N
HARMON KARDON	AV1200	4	N	N
HARMON KARDON	AVP2	3	Y	N
HARMON KARDON	AVR15	3	Y	N
HARMON KARDON	AVR20	4	N	N
HARMON KARDON	AVR25 II	4	N	N
HARMON KARDON	AVR30	4	N	N
HARMON KARDON	AVR65	4	N	N
HARMON KARDON	AVR80	4	N	N
HARMON KARDON	AVR85	4	N	N
HARMON KARDON	CITATION 22	4	N	N
HARMON KARDON	CITATION 25	3	N	N
HARMON KARDON	CITATION 5.0	3	N	N
HARMON KARDON	CITATION 5.1	4	N	N
HARMON KARDON	CITATION 7.0	4	N	N
HARMON KARDON	CITATION 7.1 (FACE ONLY)	5	N	N
HARMON KARDON	CITATION23	2	N	N
HARMON KARDON	DC520	4	Y	N
HARMON KARDON	DC5300	4	N	N
HARMON KARDON	DC5700	4	N	N
HARMON KARDON	EQ8	3	Y	N
HARMON KARDON	FL8300	3	N	N
HARMON KARDON	FL8350	4	N	N
HARMON KARDON	FL8400	3	N	N
HARMON KARDON	FL8450	3	N	N
HARMON KARDON	HD7225	3	N	N
HARMON KARDON	HD7450	3	N	N
HARMON KARDON	HD7525	3	N	N
HARMON KARDON	HK3250	4	N	N
HARMON KARDON	HK3270	4	N	N
HARMON KARDON	HK3400	3	N	N
HARMON KARDON	HK3550	3	Y	N
HARMON KARDON	HK3600	3	N	N
HARMON KARDON	HK620	3	Y	N
HARMON KARDON	HK795I	4	Y	N
HARMON KARDON	PA2100	3	Y	N
HARMON KARDON	PA2200	4	Y	N
HARMON KARDON	PA2400	4	Y	N
HARMON KARDON	PT2300	4	N	N
HARMON KARDON	TD212	3	Y	N
HARMON KARDON	TD392	3	Y	Y
HARMON KARDON	TD420	4	Y	N
HARMON KARDON	TD4200	3	N	Y
HARMON KARDON	TU905	2	Y	N
HARMON KARDON	TU909	2	Y	N
HARMON KARDON	TU930	2	N	N
HARMON KARDON	TU9600	2	N	N
HARMON VIDEO	ALD1	3	N	N
HAYES	ACCURA	2	N	Y

HEWLETT PACKARD	3400A	4	N	N
HEWLETT PACKARD	3440A	4	N	N
HEWLETT PACKARD	350D	4	N	N
HEWLETT PACKARD	3593A	6	N	N
HEWLETT PACKARD	5382A	3	N	N
HEWLETT PACKARD	6000	3	N	N
HEWLETT PACKARD	70096	8	N	Y
HEWLETT PACKARD	A2655A	2	N	Y
HEWLETT PACKARD	A4027	2	N	Y
HEWLETT PACKARD	A4032	10	N	Y
HEWLETT PACKARD	D2804B	8	N	Y
HEWLETT PACKARD	D2821	8	N	Y
HEWLETT PACKARD	D2825	8	N	Y
HEWLETT PACKARD	PLUS 3	2	N	Y
HEWLETT PACKARD	SURE STORE	5	N	N
HEWLETT PACKARD	SVGA1024I	8	N	Y
HEWLETT PACKARD	VECTRA	4	N	N
HITACHI	13GA1BA	9	N	Y
HITACHI	CT1396	8	N	Y
HITACHI	D2200M	4	N	N
HITACHI	DA501	3	N	N
HITACHI	DAC70	4	N	N
HITACHI	DE26	3	N	N
HITACHI	DW800	3	N	N
HITACHI	F372	3	N	Y
HITACHI	F482	3	N	Y
HITACHI	F494	3	N	Y
HITACHI	FT1	2	N	N
HITACHI	FX631	3	N	Y
HITACHI	HDS100R	2	N	Y
HITACHI	HTA4000	3	N	N
HITACHI	RCC10	2	N	N
HITACHI	UX605	3	N	Y
HITACHI	UX615	3	N	Y
HITACHI	UX617	3	N	Y
HITACHI	V089	3	N	N
HITACHI	V099	3	N	N
HITACHI	V1100A	4	N	N
HITACHI	VT1720A	3	N	N
HITACHI	VT2600A	3	N	N
HITACHI	VT3800A	3	N	N
HITACHI	VT498EM	3	N	N
HITACHI	VT4990EM	3	N	N
HITACHI	VTF350A	3	N	N
HITACHI	VTF372A	3	N	Y
HITACHI	VTF381	3	N	Y
HITACHI	VTF382A	3	N	Y
HITACHI	VTF392A	3	N	Y
HITACHI	VTF494	3	N	Y
HITACHI	VTF99EM	3	N	Y
HITACHI	VTFX623A	3	N	Y
HITACHI	VTM137A	3	N	N

HITACHI	VTM260A	3	N	N
HITACHI	VTM598	3	N	N
HITACHI	VTM70EM	3	N	Y
HITACHI	VTM768EM	3	N	Y
HITACHI	VTP1000	3	N	N
HITACHI	VTP3000	3	N	N
HITACHI	VTS730A	3	N	Y
HITACHI	VTS751A	3	N	Y
HITACHI	VTS772A	3	N	Y
HITACHI	VTUX625A	3	N	Y
HITACHI	VTUX627A	3	N	Y
HITACHI	VTUX717	3	N	Y
HITACHI	VTX617A	3	N	Y
HITACHI	VY170	3	N	N
HORIZON	SR2000	2	N	N
HORTRONIC	AR31	2	N	N
HOUSTON TRACKER	SYSTEM30	3	N	N
HOUSTON TRACKER	SYSTEM70	3	N	N
HOUSTON TRACKER	SYSTEMS X "ROMAN #"	3	N	N
HOUSTON TRACKER	V111	3	N	N
HUGHES	HIRDB2	2	N	Y
HUGHES	HIRDB2	2	N	Y
HUGHES	KA100	3	N	N
HYUNDAI	HL4848F	8	N	Y
IBM	14PT	10	N	Y
IBM	17V	10	N	Y
IBM	250	3	N	Y
IBM	55SX	3	N	N
IBM	7210	2	N	N
IBM	G40	9	N	Y
IBM	NOM018	4	N	N
IBM	POWERDISPLAY17	10	N	Y
IBM	PS250	4	N	N
ICOM	IC725	3	N	N
ICOM	ICF1020 -2	2	N	Y
ICOM	ICR7000	3	N	N
ICOM	ICR7100	3	N	Y
IDM	DISPLAY	3	N	N
IDM	DISPLAY MONITOR	6	N	Y
IKEGAMI	PM175B	9	N	Y
IKEGAMI	PM509	4	N	N
INFINITY	CROSSOVER	2	N	N
INFOCUS	LITESHOW II	2	N	Y
INKEL	PA4000	4	N	N
INKEL	PA935	3	N	N
INLINE	3502	2	N	Y
INMAC	DUALMOUNT	2	N	N
INMAC	SINMOUNT	2	N	N
INTEG. NETWORK	101SDT10A	2	N	N
INTELLIPOWER	525	2	N	N
INTERMEC	9570	2	N	Y
IOMEGA	JAZ	2	N	N

IOMEGA	ZIP100	2	N	N
JANIS	1A	3	N	N
JBL	4406	6	N	N
JBL	6210	2	N	N
JBL	CONTROL 1 "4SP FLAT PANEL"	4	N	Y
JBL	DIRECTOR	2	N	N
JBL	SYNTHESIS	3	N	N
JBL	TC1	3	Y	N
JDS	IRXP2	2	N	Y
JDS	TCM2W	2	N	Y
JEFF ROWLAND	IRR700	2	N	N
JENSEN	AVS2100	2	N	N
JERROLD	450 DRZIN3A	2	N	N
JERROLD	DCR 4000s	2	N	N
JERROLD	RC550	2	N	N
JERROLD	WNR2024	2	N	N
JERROLD STARCOM	7V	2	N	Y
JERROLD STARCOM	DCR3000	2	N	N
JERROLD STARCOM	DPV5210R2	2	N	N
JERROLD STARCOM	IMPULSE	2	N	N
JERROLD STARCOM	V1	2	N	N
JVC	AXV1050TN	5	N	Y
JVC	AXZ911	4	N	N
JVC	BR3100U	3	N	N
JVC	BR3200U	3	N	Y
JVC	BR3500U	3	N	N
JVC	BR3900U	3	N	Y
JVC	BR6400TR	4	N	N
JVC	BR7000UR	5	N	N
JVC	BRS378U	4	N	Y
JVC	BRS600U	3	N	N
JVC	BRS601MU	3	N	N
JVC	BRS605UB	4	N	N
JVC	BRS611U	5	N	N
JVC	BRS800U	4	N	N
JVC	C13710	8	N	Y
JVC	C13811	8	N	Y
JVC	DD5	3	N	N
JVC	DD9	3	Y	N
JVC	FX1100	3	N	N
JVC	FX33	2	N	N
JVC	FX555	2	N	N
JVC	HMDSR100RU	4	N	Y
JVC	HRA34U	3	N	N
JVC	HRA43U	3	N	Y
JVC	HRA53U	3	N	Y
JVC	HRA61U	3	N	N
JVC	HRD180U	3	N	N
JVC	HRD257MS	3	N	N
JVC	HRD337MS	3	N	Y
JVC	HRD360U	3	N	N
JVC	HRD370A	3	N	N

JVC	HRD370U	3	N	N
JVC	HRD4050U	3	N	N
JVC	HRD410U	3	N	N
JVC	HRD470U	3	N	N
JVC	HRD520U	3	N	N
JVC	HRD530U	3	N	N
JVC	HRD570U	3	N	Y
JVC	HRD750U	3	N	N
JVC	HRD780U	3	N	N
JVC	HRD830U	3	N	N
JVC	HRD840	3	N	Y
JVC	HRD865U	3	N	N
JVC	HRD910U	3	N	N
JVC	HRD960U	3	N	N
JVC	HRDD740U	3	N	Y
JVC	HRDD840U	3	N	Y
JVC	HRDX42U	3	N	N
JVC	HRJ210U	3	N	N
JVC	HRJ400U	3	N	N
JVC	HRJ440U	3	N	Y
JVC	HRJ600U	3	N	N
JVC	HRJ610U	3	N	N
JVC	HRJ620U	3	N	N
JVC	HRJ640U	3	N	Y
JVC	HRJ647MS	3	N	Y
JVC	HRS3500U	3	N	N
JVC	HRS3500U	3	N	Y
JVC	HRS4500U	3	N	N
JVC	HRS4700U	3	N	N
JVC	HRS4900U	3	N	Y
JVC	HRS5000U	3	N	N
JVC	HRS5100	3	N	Y
JVC	HRS5200	3	N	Y
JVC	HRS5300U	3	N	Y
JVC	HRS5400U	3	N	Y
JVC	HRS5500U	3	N	N
JVC	HRS5800U	3	N	Y
JVC	HRS6600U	3	N	Y
JVC	HRS6700U	3	N	Y
JVC	HRS6800U	3	N	Y
JVC	HRS6900U	3	N	Y
JVC	HRS7000U	3	N	N
JVC	HRS7100U	3	N	Y
JVC	HRS7200U	3	N	Y
JVC	HRS7300U	3	N	Y
JVC	HRS7500U	3	N	Y
JVC	HRS8000U	3	N	N
JVC	HRS9400U	3	N	N
JVC	HRS9500U	3	N	Y
JVC	HRSC1000U	3	N	N
JVC	HRVP612	3	N	Y
JVC	HRVP616U	3	N	Y

JVC	HRVP624U	3	N	Y
JVC	HRVP634	3	N	Y
JVC	HRVP636U	3	N	Y
JVC	HRVP638U	3	N	Y
JVC	HRVP644U	3	N	Y
JVC	HRVP650U	3	N	Y
JVC	HRVP654U	3	N	Y
JVC	HRVP66V	3	N	N
JVC	HRVP700U	3	N	N
JVC	HRVP830U	3	N	Y
JVC	JVCBRS600U	3	N	N
JVC	JXS100	2	N	N
JVC	JXS300	2	N	N
JVC	JXS700	3	N	Y
JVC	JXS900	3	N	N
JVC	KDV6	3	N	N
JVC	KDW55	3	N	N
JVC	KDX3	3	N	N
JVC	RX1001V	4	N	N
JVC	RX206	3	N	N
JVC	RX212	3	N	N
JVC	RX220	3	N	N
JVC	RX250	3	N	N
JVC	RX307TN	3	N	N
JVC	RX315TN	4	N	N
JVC	RX317	3	N	N
JVC	RX500	3	N	N
JVC	RX550	3	N	N
JVC	RX554V	4	N	Y
JVC	RX664V	4	N	Y
JVC	RX750V	4	N	N
JVC	RX815TN	4	N	N
JVC	RX905V	4	N	Y
JVC	RX950VBK	4	N	N
JVC	SAK27U	4	N	N
JVC	SEAM770	3	N	N
JVC	SR3260U	3	N	Y
JVC	SR3360U	3	N	Y
JVC	SR9070U	3	N	Y
JVC	SRL901V	3	N	N
JVC	SRS365U	3	N	Y
JVC	SUA30	2	N	N
JVC	SWR320U	5	Y	N
JVC	TDR272BK	4	N	N
JVC	TDR421	3	N	N
JVC	TDR431	3	N	N
JVC	TDR441	3	N	N
JVC	TDR461	4	N	N
JVC	TDR462	4	N	N
JVC	TDV1010	4	N	N
JVC	TDV541	4	N	N
JVC	TDV661	4	N	N

JVC	TDV711	4	N	N
JVC	TDW103	3	N	N
JVC	TDW106	3	N	N
JVC	TDW207	4	N	N
JVC	TDW209TN	4	N	N
JVC	TDW215	4	N	N
JVC	TDW30	3	N	N
JVC	TDW307	4	N	N
JVC	TDW309	4	N	N
JVC	TDW309TN	4	N	N
JVC	TDW317	4	N	N
JVC	TDW330	3	N	N
JVC	TDW444	3	N	N
JVC	TDW501	3	N	N
JVC	TDW505	4	N	N
JVC	TDW550	3	N	N
JVC	TDW660	3	N	N
JVC	TDW707	4	N	N
JVC	TDW709	4	N	N
JVC	TDW717	4	N	N
JVC	TDW718	4	N	N
JVC	TDW803	4	N	N
JVC	TDW805	4	N	N
JVC	TDW901	4	N	Y
JVC	TDW999	4	N	N
JVC	TM131SU	8	N	Y
JVC	TM13U	9	N	N
JVC	TM22	4	N	Y
JVC	TM550U	4	N	N
JVC	TM63U	3	N	N
JVC	TM900SU	6	N	N
JVC	TM9UA	6	N	N
JVC	TMA9U	6	N	N
JVC	TR87	2	N	N
JVC	TX300	2	N	N
JVC	VSG11	3	N	N
JVC	XDZ1010	4	N	Y
JVC	XDZ1100	3	N	N
JVC	XDZ507	4	N	N
JVC	XLF108	3	N	N
JVC	XLF154BK	4	N	Y
JVC	XLF207TN	4	N	N
JVC	XLF215TN	4	N	N
JVC	XLF254	4	N	Y
JVC	XLF254	2	N	N
JVC	XLG512	3	N	N
JVC	XLGM800	4	N	N
JVC	XLM318	3	N	N
JVC	XLM400	3	N	N
JVC	XLM409TN	4	N	N
JVC	XLM415	4	N	N
JVC	XLM417TN	3	N	N

JVC	XLM418	4	N	N
JVC	XLM500	3	N	N
JVC	XLM509	4	N	N
JVC	XLM600	3	N	N
JVC	XLM700	3	N	N
JVC	XLMC100CHNGR.	9	N	Y
JVC	XLMC100CNTRL.	3	N	N
JVC	XLMC222	5	N	Y
JVC	XLMC301 CHANGER	9	N	Y
JVC	XLMC302 CONTROLLER	3	N	N
JVC	XLMC334	5	N	Y
JVC	XLSV22BK	3	N	N
JVC	XLV1100BK	3	N	Y
JVC	XLV111	3	N	N
JVC	XLV114	3	N	N
JVC	XLV151TN	3	N	N
JVC	XLV161TN	3	N	N
JVC	XLV250	3	N	N
JVC	XLV261	3	N	N
JVC	XLZ555	3	N	N
JVC	XPA1000	3	N	N
KALEILIGHT	K20X	4	N	Y
KDS	VS4	9	N	Y
KENWOOD	1050CD	3	N	N
KENWOOD	1050CT	4	N	N
KENWOOD	BASSICM2	4	N	N
KENWOOD	DP2030	3	N	N
KENWOOD	DP48	3	N	N
KENWOOD	DPJ1070	5	N	N
KENWOOD	DPJ2070	5	N	N
KENWOOD	DPM107R	3	N	N
KENWOOD	DPM6620	4	N	N
KENWOOD	DPR3080	3	N	N
KENWOOD	DPR4060	3	N	N
KENWOOD	DPR4440	4	N	N
KENWOOD	DPR6080	3	N	Y
KENWOOD	DPR892	3	N	N
KENWOOD	GE770B	4	N	N
KENWOOD	KA770B	4	N	N
KENWOOD	KA89	4	N	N
KENWOOD	KA892	4	N	N
KENWOOD	KAV6000	4	N	N
KENWOOD	KCX1	4	N	Y
KENWOOD	KCZ1	4	N	Y
KENWOOD	KMX1	4	N	N
KENWOOD	KMX1000	3	N	N
KENWOOD	KMZ1	4	N	Y
KENWOOD	KRA5010	4	N	N
KENWOOD	KRA5030	4	N	N
KENWOOD	KRA5040	4	N	N
KENWOOD	KRA5080	3	N	N
KENWOOD	KRV990D	4	N	N

KENWOOD	KT56	2	N	N
KENWOOD	KT57	2	N	N
KENWOOD	KT59	2	N	N
KENWOOD	KT592	2	N	N
KENWOOD	KT880	2	N	N
KENWOOD	KV936HF	3	N	Y
KENWOOD	KX46C	3	N	N
KENWOOD	KX56CW	3	N	N
KENWOOD	KXW1060	4	N	N
KENWOOD	KXW6020	4	N	N
KENWOOD	KXW6040	4	N	N
KENWOOD	KXW8010	4	N	N
KENWOOD	KXW8020	4	N	N
KENWOOD	KXW8030	4	N	N
KENWOOD	KXW892	4	N	N
KENWOOD	LVD300	4	N	N
KENWOOD	SC75B	2	N	N
KENWOOD	SP940	4	N	Y
KENWOOD	SW200	2	N	N
KENWOOD	TM 461A	2	N	N
KENWOOD	TM241A	2	N	Y
KENWOOD	TM261A	2	N	N
KENWOOD	TMV7A	2	N	N
KENWOOD	TS60S	3	N	Y
KFC	MONITOR	8	N	Y
KINERGETICS	SW200	2	N	N
KLOSS	T2	2	N	N
KNOLL	MR1250	3	N	Y
KODAK	PCD270	3	N	N
KODAK	PCD5850	3	N	N
KODAK	PCD5870	3	N	N
KODAK	PCD850	3	N	N
KODAK	PCD870	3	N	N
KOMODO	K40	9	N	Y
KRAMER	VS6E11	2	N	N
KRELL	250M	7	N	Y
KYOCERA	DA710CX	3	N	N
KYOCERA	T910	3	N	N
LABTEC	MCS1400	6	N	Y
LAKE SHORE	420 GAUSSMETER	3	N	Y
LEADER	LAG26	4	N	N
LEADER	LAV192	4	N	N
LEADER	LBO550A	7	N	Y
LECTROSONICS	R185	2	N	Y
LEXICON	412	4	N	N
LEXICON	CP1	2	N	N
LEXICON	CP2	2	N	N
LEXICON	CP3	3	N	N
LEXICON	CP3+	3	N	N
LEXICON	DC-1	3	N	N
LINK	LN14+	9	N	Y
LINN	AKTIV	2	N	Y

LINN	AV5105	2	N	Y
LINN	LK1	2	N	N
LINN	LK2	2	N	N
LINN	RER16	2	N	N
LINN	SES8	2	N	N
LITETOUCH	2000	3	N	Y
LUXMAN	A383	5	N	Y
LUXMAN	D111	3	N	N
LUXMAN	D373	3	N	Y
LUXMAN	D375	3	N	Y
LUXMAN	DC113	3	N	N
LUXMAN	DC114	3	N	N
LUXMAN	DZ 112	3	N	N
LUXMAN	G120A	3	N	N
LUXMAN	K105	3	N	N
LUXMAN	K110W	3	N	N
LUXMAN	K111	3	N	N
LUXMAN	K112	3	N	N
LUXMAN	K351	3	N	Y
LUXMAN	K373	3	N	Y
LUXMAN	K8	3	N	N
LUXMAN	KX100	4	Y	N
LUXMAN	L580	4	N	N
LUXMAN	LV103	4	N	N
LUXMAN	LV117	4	N	N
LUXMAN	R115	4	N	N
LUXMAN	R117	4	N	N
LUXMAN	T100	2	N	N
LUXMAN	T107	3	N	N
LUXMAN	T111	2	N	N
LUXMAN	T117	2	N	N
LUXMAN	T353	3	N	Y
LUXMAN	T407	3	N	N
LUXMAN	T450	3	N	N
LUXMAN	TP114	3	N	N
LUXMAN	TP117	3	N	N
LUXMAN	U100	2	N	N
MADRIGAL	SEE PROCEED	2	N	
MAGNAVOX	7BM749CHO1	8	N	Y
MAGNAVOX	CD2000	2	N	N
MAGNAVOX	CD2040	3	N	N
MAGNAVOX	CDB266	3	N	N
MAGNAVOX	CDB470	2	N	N
MAGNAVOX	CDB480	2	N	N
MAGNAVOX	CDB486	3	N	N
MAGNAVOX	CDB496	3	N	N
MAGNAVOX	CDB583	3	N	N
MAGNAVOX	CDB586	3	N	N
MAGNAVOX	CDB650BK	3	N	N
MAGNAVOX	CDC550	3	N	N
MAGNAVOX	CDC745	3	N	N
MAGNAVOX	CDI200	3	N	N

MAGNAVOX	CDV305	4	N	N
MAGNAVOX	CM2015	8	N	Y
MAGNAVOX	FD1051BX01	3	N	N
MAGNAVOX	HSU65	3	N	N
MAGNAVOX	MX145	8	N	Y
MAGNAVOX	RDO510	4	N	Y
MAGNAVOX	RDO510C103	4	N	Y
MAGNAVOX	UR4342AT02	3	N	N
MAGNAVOX	VR9243	3	N	Y
MAGNAVOX	VR9362	3	N	Y
MAGNAVOX	VR9668AT01	3	N	N
MAGNAVOX	VR9745AT01	3	N	N
MAGNAVOX	VR977OATO1	3	N	N
MAGNAVOX	VR9780AT01	3	N	N
MAGNAVOX	VR9870AT01	3	N	N
MAGNAVOX	VRT342AT02	3	N	Y
MAGNAVOX	VRU562	3	N	Y
MAINSTREAM	PROSAT11	2	N	Y
MARANTZ	AV550	3	N	
MARANTZ	AV600	3	N	N
MARANTZ	CC45	3	N	N
MARANTZ	CC47	3	N	Y
MARANTZ	CC48	3	N	Y
MARANTZ	CC52	3	N	
MARANTZ	CC65	3	N	N
MARANTZ	CC65SE	3	N	N
MARANTZ	CC67	3	N	N
MARANTZ	CC870	5	N	N
MARANTZ	CD17	2	N	N
MARANTZ	CD310	4	N	N
MARANTZ	CD53	3	N	N
MARANTZ	CD63	3	N	N
MARANTZ	CLDV510	4	N	N
MARANTZ	DD82	4	N	N
MARANTZ	DP870	3	N	N
MARANTZ	DR700	3	N	N
MARANTZ	DVD810	2	N	N
MARANTZ	DVD810	3	N	N
MARANTZ	DVD930	2	N	Y
MARANTZ	EC500	3	N	N
MARANTZ	LV500	4	N	N
MARANTZ	LV510	4	N	N
MARANTZ	LV520	4	N	N
MARANTZ	LV520	3	N	N
MARANTZ	MA500	4	N	N
MARANTZ	MA500 X 5 UNITS	4	N	N
MARANTZ	MA700	4	N	N
MARANTZ	MM500	4	N	N
MARANTZ	MV510	3	N	Y
MARANTZ	MV610	3	N	N
MARANTZ	MV830	3	N	Y
MARANTZ	MV880	3	N	Y

MARANTZ	PM265AVK	2	N	N
MARANTZ	PM57	3	N	N
MARANTZ	SD455	4	N	N
MARANTZ	SD525	4	N	N
MARANTZ	SD535	4	N	N
MARANTZ	SD545	4	N	N
MARANTZ	SD555	4	N	N
MARANTZ	SD63	4	N	N
MARANTZ	SD74	3	N	N
MARANTZ	SR48 (FACE ONLY)	4	N	N
MARANTZ	SR480	4	Y	N
MARANTZ	SR63	4	N	Y
MARANTZ	SR66	4	N	N
MARANTZ	SR680	4	N	N
MARANTZ	SR73	4	N	N
MARANTZ	SR82MK2	4	N	N
MARANTZ	SR870	4	N	N
MARANTZ	SR880U	4	N	N
MARANTZ	SR92	4	N	N
MARANTZ	SR96	4	N	N
MARANTZ	ST46	3	N	Y
MARANTZ	ST50	3	N	N
MARANTZ	ST53	3	N	N
MARK LEVINSON	#26S	2	Y	Y
MATRIX	VIP	3	Y	N
MAX TECH	XT4888	9	N	Y
McCORMACK	MHD0125	2	N	N
MCINTOSH	C39(FL)	5	N	N
MCINTOSH	C39(S)	5	N	N
MCINTOSH	C40(FL)	4	N	N
MCINTOSH	C40(S)	4	N	N
MCINTOSH	CR15(FL)	3	N	N
MCINTOSH	CR15(S)	3	N	N
MCINTOSH	CR7	3	N	N
MCINTOSH	CR8	3	N	N
MCINTOSH	M2494	10	N	Y
MCINTOSH	MA6450(FL)	4	N	N
MCINTOSH	MA6450(S)	4	N	N
MCINTOSH	MAC3(FL)	3	N	N
MCINTOSH	MAC3(S)	3	N	N
MCINTOSH	MAC4300V	4	Y	N
MCINTOSH	MC1000(FACE ONLY)	6	N	Y
MCINTOSH	MC122(FL)	3	N	N
MCINTOSH	MC122(S)	3	N	N
MCINTOSH	MC300(FL)	5	N	N
MCINTOSH	MC300(S)	5	Y	N
MCINTOSH	MC7100	3	N	N
MCINTOSH	MC7106(FL)	5	N	N
MCINTOSH	MC7106(S)	5	N	N
MCINTOSH	MC7205(FL)	5	N	N
MCINTOSH	MC7205(S)	5	N	N
MCINTOSH	MCD7008	4	N	N

MCINTOSH	MCD7009	4	N	N
MCINTOSH	MCD7010(FL)	4	N	N
MCINTOSH	MCD7010(S)	4	N	N
MCINTOSH	MLD7020(FL)	5	N	N
MCINTOSH	MLD7020(S)	5	N	N
MCINTOSH	MR7083	4	N	N
MCINTOSH	MR7084(FL)	3	N	N
MCINTOSH	MR7084(S)	3	N	N
MCINTOSH	MX115	4	N	N
MCM	325190	2	N	N
MCS	3574	4	N	N
MEGASTAR	VKA280	4	N	N
MERIDIAN	207A	3	N	N
MERIDIAN	207B	3	N	N
MERIDIAN	500	3	N	N
MERIDIAN	504	3	N	N
MERIDIAN	508	3	N	N
MERIDIAN	519	2	N	N
MERIDIAN	557	5	N	N
MERIDIAN	562V	3	N	N
MERIDIAN	563	3	N	N
MERIDIAN	565	3	N	N
MERIT	CRM1005	4	N	N
MERLIN	ME158S	4	N	N
MFJ	MFJ1278B	2	N	N
MFJ	MFJ407B	2	N	N
MFJ	MFJ949E	3	N	N
MGA	HS4112UR	3	N	N
MICRO Q	SM1421	7	N	N
MICRON	MDR530	2	N	N
MIDLAND	70-0351C	2	N	Y
MIDLAND	70144DB	3	N	Y
MILLENIUM	2.4.6.	2	N	N
MIRAGE	LFX3	2	N	Y
MITSUBISHI	15HX	9	N	Y
MITSUBISHI	15VX	8	N	N
MITSUBISHI	17HX	10	N	Y
MITSUBISHI	17TX	10	N	Y
MITSUBISHI	AM1401R	9	N	N
MITSUBISHI	AUM1371A	8	N	N
MITSUBISHI	AUM1381A	8	N	N
MITSUBISHI	AUM1391A	8	N	N
MITSUBISHI	BV1000	4	N	N
MITSUBISHI	BV2000	4	N	N
MITSUBISHI	CP10U	3	N	Y
MITSUBISHI	CS13101	8	N	Y
MITSUBISHI	CS13103	8	N	Y
MITSUBISHI	CS13201	8	N	Y
MITSUBISHI	CS1347R	8	N	N
MITSUBISHI	DD1000	2	N	N
MITSUBISHI	DD2000	2	N	N
MITSUBISHI	DP105	10	N	Y

MITSUBISHI	DP309	3	N	N
MITSUBISHI	DP411R	3	N	N
MITSUBISHI	DT156	4	N	N
MITSUBISHI	DT1567	4	N	N
MITSUBISHI	DT160	4	N	N
MITSUBISHI	FA3435	8	N	Y
MITSUBISHI	HS402UR	3	N	Y
MITSUBISHI	HS410UR	3	N	N
MITSUBISHI	HS413UR	3	N	N
MITSUBISHI	HS421UR	3	N	N
MITSUBISHI	HS423UR	3	N	N
MITSUBISHI	HS430UR	3	N	N
MITSUBISHI	HS5425	3	N	N
MITSUBISHI	HSU100	3	N	Y
MITSUBISHI	HSU200	3	N	Y
MITSUBISHI	HSU260	3	N	Y
MITSUBISHI	HSU31	3	N	N
MITSUBISHI	HSU32	3	N	N
MITSUBISHI	HSU34	3	N	N
MITSUBISHI	HSU38	3	N	Y
MITSUBISHI	HSU410	3	N	Y
MITSUBISHI	HSU420	3	N	Y
MITSUBISHI	HSU422R	3	N	Y
MITSUBISHI	HSU430	3	N	N
MITSUBISHI	HSU440	3	N	N
MITSUBISHI	HSU48	3	N	N
MITSUBISHI	HSU50	3	N	N
MITSUBISHI	HSU500	3	N	Y
MITSUBISHI	HSU51	3	N	N
MITSUBISHI	HSU510	3	N	Y
MITSUBISHI	HSU52	3	N	N
MITSUBISHI	HSU520	3	N	N
MITSUBISHI	HSU53	3	N	Y
MITSUBISHI	HSU530	3	N	Y
MITSUBISHI	HSU54	3	N	N
MITSUBISHI	HSU540	3	N	Y
MITSUBISHI	HSU55	3	N	Y
MITSUBISHI	HSU550	3	N	Y
MITSUBISHI	HSU56	3	N	N
MITSUBISHI	HSU560	3	N	Y
MITSUBISHI	HSU570	3	N	N
MITSUBISHI	HSU58	3	N	N
MITSUBISHI	HSU580	3	N	Y
MITSUBISHI	HSU59	3	N	Y
MITSUBISHI	HSU590	3	N	N
MITSUBISHI	HSU61	3	N	Y
MITSUBISHI	HSU62	3	N	Y
MITSUBISHI	HSU650	3	N	Y
MITSUBISHI	HSU67	3	N	Y
MITSUBISHI	HSU680	3	N	Y
MITSUBISHI	HSU69	3	N	Y
MITSUBISHI	HSU70	3	N	N

mitsubishi	HSU71	3	N	N
mitsubishi	HSU760	3	N	Y
mitsubishi	HSU780	3	N	Y
mitsubishi	HSU781	3	N	Y
mitsubishi	HSU790	3	N	Y
mitsubishi	HSU80	4	N	Y
mitsubishi	HSU82	3	N	Y
mitsubishi	HTS100	4	N	N
mitsubishi	HTS300	5	N	N
mitsubishi	MC4030	3	N	N
mitsubishi	MR7020	4	N	N
mitsubishi	MR8010	4	N	N
mitsubishi	MT5100	4	N	N
mitsubishi	MU6022	4	N	N
mitsubishi	MV6027	4	N	N
mitsubishi	MV7025	4	N	N
mitsubishi	MVR600	4	N	N
mitsubishi	P67UA	3	N	Y
mitsubishi	SD4561	8	N	Y
mitsubishi	SD4561CA	8	N	Y
mitsubishi	SD5500C	8	N	Y
mitsubishi	SD5700C	9	N	Y
mitsubishi	SD5904C	8	N	Y
mitsubishi	TFM8705SKHKW	10	N	Y
mitsubishi	TX102R	2	N	N
mitsubishi	U110	3	N	Y
mitsubishi	U28	3	N	Y
mitsubishi	U31	3	N	N
mitsubishi	U32	3	N	N
mitsubishi	U34	3	N	N
mitsubishi	U38	3	N	Y
mitsubishi	U50	3	N	N
mitsubishi	U51	3	N	N
mitsubishi	U52	3	N	N
mitsubishi	U54	3	N	N
mitsubishi	U55	3	N	Y
mitsubishi	U56	3	N	N
mitsubishi	U570	3	N	N
mitsubishi	U58	3	N	N
mitsubishi	U65	3	N	N
mitsubishi	U770	3	N	Y
mitsubishi	VC1250	4	N	Y
mitsubishi	WB2000	2	N	N
mitsubishi	XC1409C	7	N	N
MOD SQUAD	SIGNATURECD	4	Y	Y
MOTOROLA	M10	2	N	Y
MOTOROLA	M100	2	N	N
MOTOROLA	M120	2	N	Y
MOTOROLA	MAX TRAC	2	N	Y
MOTOROLA	STARMAX 3000/180	3	N	N
MOTOROLA	V3400	2	N	N
MTS	VDC212	2	N	Y

MULTI TECH	CH.PLUS(4239)	2	N	Y
MULTI TECH	CHANNELPLUS	2	N	N
MULTI TECH	MT932LA	2	N	N
MULTIVISION	3.1	2	N	Y
MUSEATEX	MELIORFMT	3	N	Y
MUSEUM TECH.	TS3000	2	N	Y
MUZAK	ADCASTER1200	3	N	N
MUZAK	MU1608	2	N	N
MUZAK	MUZAK1600	3	N	N
N.E.C.A.	DESKTOPPC	5	N	Y
NAD	1300	3	N	N
NAD	1600	3	N	N
NAD	2100	3	N	N
NAD	214	4	N	N
NAD	2400	4	N	N
NAD	302	3	N	N
NAD	3225PE	3	N	N
NAD	3400	4	N	N
NAD	412	3	N	N
NAD	4150	2	N	N
NAD	4225	2	N	N
NAD	4300	3	N	N
NAD	505	3	N	N
NAD	517	3	N	N
NAD	5170	3	N	N
NAD	5220	3	N	N
NAD	523	3	N	N
NAD	5255	3	N	N
NAD	5330	3	N	N
NAD	6100	3	N	N
NAD	6155	3	N	N
NAD	616	3	N	N
NAD	6240	3	N	N
NAD	7140	3	N	N
NAD	7155	3	N	N
NAD	7220PE	3	N	N
NAD	7240PE	3	N	N
NAD	906	3	N	N
NAD	916	4	N	N
NAD	917	4	N	N
NAD	AV716	5	Y	N
NAD	MR13	8	N	Y
NADY	1CX3	2	N	N
NADY	IRCU300	3	N	N
NAKAMICHI	480	4	Y	N
NAKAMICHI	AV1	4	N	N
NAKAMICHI	AV1s	4	N	N
NAKAMICHI	AV2	4	N	N
NAKAMICHI	BX1	3	N	N
NAKAMICHI	BX125	3	N	N
NAKAMICHI	BX300	3	N	N
NAKAMICHI	CA2	3	N	N

NAKAMICHI	CA5	2	N	N
NAKAMICHI	CA7A	3	N	N
NAKAMICHI	CASSETTEDECK2	3	N	N
NAKAMICHI	CDC3A	3	N	N
NAKAMICHI	CDC4A	3	N	N
NAKAMICHI	CDP2A	3	N	N
NAKAMICHI	CDPLAYER2	3	N	N
NAKAMICHI	CDPLAYER3	3	N	N
NAKAMICHI	CDPLAYER4	3	N	N
NAKAMICHI	CR3A	3	N	N
NAKAMICHI	CR7A	4	N	N
NAKAMICHI	CS2	3	N	N
NAKAMICHI	DR3	3	N	N
NAKAMICHI	DRAGON	4	Y	N
NAKAMICHI	IA1Z	5	N	N
NAKAMICHI	LX3	4	Y	N
NAKAMICHI	MB1	3	N	N
NAKAMICHI	MB2	3	N	N
NAKAMICHI	MB2S	3	N	N
NAKAMICHI	MB3	3	N	N
NAKAMICHI	MB3s	3	N	N
NAKAMICHI	MB4s	3	N	N
NAKAMICHI	OMS1A	3	N	N
NAKAMICHI	OMS2A	3	N	N
NAKAMICHI	OMS5	3	N	N
NAKAMICHI	OMS7	3	N	N
NAKAMICHI	OMS7AII	3	N	N
NAKAMICHI	PA5	4	N	N
NAKAMICHI	PA5AII	4	N	N
NAKAMICHI	PA7	4	Y	N
NAKAMICHI	PA7	6	N	N
NAKAMICHI	RE2	3	N	N
NAKAMICHI	RE3	3	N	N
NAKAMICHI	RECEIVER1	3	N	Y
NAKAMICHI	RECEIVER2	3	N	Y
NAKAMICHI	RX202	4	Y	N
NAKAMICHI	RX303	4	Y	N
NAKAMICHI	RX505	4	Y	N
NAKAMICHI	SR4A	3	N	N
NAKAMICHI	ST7	2	N	N
NAKAMICHI	TA2A	3	N	N
NAKAMICHI	TA3A	3	N	N
NANAO	F215	9	N	Y
NANAO	F560iW	9	N	Y
NATIONAL	NVG500EM	3	N	Y
NCI	VR100	2	N	N
NEC	2010CPU	5	N	Y
NEC	3FGE	10	N	Y
NEC	4FG	10	N	Y
NEC	966U	3	N	N
NEC	A1300E	4	N	N
NEC	AU350	3	N	N

NEC	AV330	3	N	N
NEC	AVX910	3	N	N
NEC	C550	9	N	N
NEC	CD530	3	N	N
NEC	CD730	3	N	N
NEC	CT1420A	9	N	N
NEC	DS8000MK11	3	N	N
NEC	DS8000U	3	N	N
NEC	DS8500U	3	N	N
NEC	DX2500U	3	N	N
NEC	DX3500	3	N	N
NEC	DX5000U	3	N	N
NEC	IDC2000	3	N	N
NEC	JC1404HMA	9	N	Y
NEC	JC1531VMA1	10	N	Y
NEC	JC1734VMA	10	N	Y
NEC	LCD1510	10	N	Y
NEC	M50	3	N	N
NEC	M500	8	N	Y
NEC	MULTISYNC2A	8	N	Y
NEC	N895EU	3	N	N
NEC	N951U	3	N	N
NEC	N955U	3	N	N
NEC	N958U	3	N	N
NEC	N959U	3	N	N
NEC	N961U	3	N	N
NEC	N965U	3	N	N
NEC	N966U	3	N	Y
NEC	N968U	3	N	N
NEC	N979U	3	N	N
NEC	NS5700U	3	N	N
NEC	PLA710	3	N	N
NEC	PM971A	6	N	N
NEC	PVS98A	3	N	N
NEC	T710	3	N	N
NEC	TU941EN	2	N	N
NEC	TV820EN	2	N	N
NEC	V133E	3	N	N
NEC	VU1210	2	N	N
NEC	XV15	8	N	Y
NET	PSW	2	N	N
NETWORK ELEC.	VDA6	2	N	N
NHT	MA1A	2	N	N
NHT	SA1	2	N	N
NHT	SA2	3	N	N
NHT	SA3	4	N	N
NIKKO	NCD200R	3	N	N
NIKKO	ND750	3	N	N
NIKKO	ND800	3	N	N
NIKKO	ND850W	3	N	N
NIKKO	T400	3	Y	N
NILES AUDIO	AB8	3	N	Y

NILES AUDIO	ADA6	2	N	N
NILES AUDIO	AXP1	2	N	N
NILES AUDIO	DPS1	2	N	N
NILES AUDIO	HDL6	2	N	N
NILES AUDIO	HDS4	2	N	N
NILES AUDIO	HDS6	2	Y	N
NILES AUDIO	IPC6	2	N	N
NILES AUDIO	IRD8	2	N	Y
NILES AUDIO	MSA10A	3	Y	N
NILES AUDIO	RVS6	2	N	Y
NILES AUDIO	SA100	3	N	Y
NILES AUDIO	SI1200	4	N	N
NILES AUDIO	SI1230	4	N	N
NILES AUDIO	SPS1	2	N	N
NILES AUDIO	SPS4	2	N	N
NILES AUDIO	SPS6	2	N	N
NILES AUDIO	SVC6	2	N	Y
NILES AUDIO	SVL2	2	N	N
NILES AUDIO	VSA1	2	N	N
NILES AUDIO	VSA5	3	N	N
NOKIA	449E	9	N	Y
NOKIA	44BS	9	N	Y
NSM	CD2100	3	N	N
NSM	CD3101	3	N	N
NTI	VOPEX4AVMML	4	N	Y
OAK	SIGMAONE	2	N	N
OCEAN	DCM 1588VA	8	N	Y
OMEGA	4151A1A-F	2	N	N
ONKYO	A807	5	N	N
ONKYO	A8700	4	N	N
ONKYO	A9310	4	Y	Y
ONKYO	ARV400	4	N	N
ONKYO	ARV401	4	Y	N
ONKYO	ASV810PRO	5	N	N
ONKYO	DVS501	3	N	Y
ONKYO	DX1700	3	N	N
ONKYO	DX200	3	N	N
ONKYO	DX2700	3	N	N
ONKYO	DX703	3	Y	Y
ONKYO	DX710	3	Y	N
ONKYO	DX7210	3	Y	Y
ONKYO	DX7711	4	N	Y
ONKYO	DX906	4	Y	N
ONKYO	DXC100	3	N	N
ONKYO	DXC201	3	Y	Y
ONKYO	DXC210	3	Y	Y
ONKYO	DXC300	3	N	N
ONKYO	DXC310	3	N	N
ONKYO	DXC320	3	Y	Y
ONKYO	DXC340	4	N	Y
ONKYO	DXC510	3	N	N
ONKYO	DXC530	3	Y	Y

ONKYO	DXC540	4	N	Y
ONKYO	DXC600	3	N	N
ONKYO	DXC606	4	N	N
ONKYO	DXC730	4	N	Y
ONKYO	DXC909	4	N	N
ONKYO	DXM505	3	Y	Y
ONKYO	EQ140	3	N	N
ONKYO	EQ201	3	Y	Y
ONKYO	EQ35	3	N	N
ONKYO	ES600PRO	3	Y	N
ONKYO	M501	4	Y	N
ONKYO	M504	5	N	N
ONKYO	M508	5	N	N
ONKYO	P301	3	Y	Y
ONKYO	P304	3	N	N
ONKYO	P3300	3	N	N
ONKYO	P388F	3	Y	Y
ONKYO	T4000	2	N	N
ONKYO	T403	2	Y	N
ONKYO	T404	2	Y	N
ONKYO	T407	3	N	N
ONKYO	T4087	2	N	N
ONKYO	T4130	2	N	N
ONKYO	T4210	3	Y	Y
ONKYO	T4300	2	N	N
ONKYO	T4310R	3	Y	Y
ONKYO	T4500	3	N	N
ONKYO	T450RDS	3	Y	Y
ONKYO	T4700	3	N	N
ONKYO	T4711	3	N	Y
ONKYO	T9090	3	N	N
ONKYO	T9090II	3	N	N
ONKYO	TA2000	3	N	N
ONKYO	TA201	3	Y	Y
ONKYO	TA201	3	Y	N
ONKYO	TA2050	3	N	N
ONKYO	TA2120	3	N	N
ONKYO	TA2200	3	N	N
ONKYO	TA2600	4	N	N
ONKYO	TA630D	4	N	N
ONKYO	TAR22	3	N	N
ONKYO	TAR240	3	N	N
ONKYO	TAR260	3	N	N
ONKYO	TAR300	3	N	N
ONKYO	TAR301	3	Y	Y
ONKYO	TAR401	3	Y	N
ONKYO	TAR410	3	Y	Y
ONKYO	TARW200	3	N	N
ONKYO	TARW313	3	Y	N
ONKYO	TARW344	3	N	Y
ONKYO	TARW404	3	Y	Y
ONKYO	TARW411	3	Y	Y

ONKYO	TARW414	3	Y	N
ONKYO	TARW470	3	N	N
ONKYO	TARW490	3	N	N
ONKYO	TARW505	3	Y	N
ONKYO	TARW544	3	N	Y
ONKYO	TARW909	4	N	N
ONKYO	TARW99	3	N	N
ONKYO	TAW450	3	N	N
ONKYO	TAW460	3	N	N
ONKYO	TG10	3	N	N
ONKYO	TX35	3	N	N
ONKYO	TX8211	4	N	Y
ONKYO	TX8511	4	N	Y
ONKYO	TX910	3	Y	N
ONKYO	TXDS747	5	N	Y
ONKYO	TXDS838	5	N	Y
ONKYO	TXDS939	5	N	Y
ONKYO	TXSV50PRO	4	N	N
ONKYO	TXSV525	5	Y	Y
ONKYO	TXSV636	5	Y	Y
ONKYO	TXSV70PRO	4	N	N
ONKYO	TXSV717PRO	5	Y	Y
ONKYO	TXSV727	5	Y	Y
ONKYO	TXSV7M	4	N	N
ONKYO	TXSV828THX	5	Y	Y
ONKYO	TXSV909PRO	5	N	N
ONKYO	TXSV90PRO	4	N	N
ONKYO	TXSV919THX	5	N	N
ONKYO	TXV940	4	Y	N
ONLINE	CPU	4	N	Y
OPTIMUS	312050	3	N	N
OPTIMUS	95	3	N	N
OPTIMUS	CD1750	2	N	N
OPTIMUS	CD5500	3	N	N
OPTIMUS	CD8100	3	N	N
OPTIMUS	SCT88	4	N	N
OPTIQUEST	Q41	8	N	Y
OPTIQUEST	V641	8	N	Y
OTARI	CB109	4	N	N
OTARI	CTM10	4	N	N
OTARI	MX50	11	N	N
P.C. ELECT.	FASTSCANREC	2	N	N
PACE	NOMADA	2	N	Y
PACKARD BELL	AXCEL 2410	3	N	Y
PALMHUB	ETHER H9+	2	N	N
PANAMAX	MAX1000	2	N	N
PANAMAX	MAX1000+	2	N	N
PANAMAX	MAX1500	3	N	N
PANASONIC	AG1260	3	N	Y
PANASONIC	AG1270	3	N	Y
PANASONIC	AG1280	3	N	Y
PANASONIC	AG1290P	3	N	Y

PANASONIC	AG1300	3	N	N
PANASONIC	AG1310	3	N	N
PANASONIC	AG1320P	3	N	N
PANASONIC	AG1320P	2	N	N
PANASONIC	AG1330	3	N	Y
PANASONIC	AG1730	3	N	N
PANASONIC	AG1740P	3	N	Y
PANASONIC	AG1800	3	N	N
PANASONIC	AG1810	3	N	N
PANASONIC	AG1820	3	N	N
PANASONIC	AG1830	3	N	Y
PANASONIC	AG1950	4	N	N
PANASONIC	AG1960	3	N	N
PANASONIC	AG1970	3	N	Y
PANASONIC	AG1980	3	N	Y
PANASONIC	AG2200	3	N	N
PANASONIC	AG2400	2	N	Y
PANASONIC	AG2500	3	N	N
PANASONIC	AG2510	3	N	N
PANASONIC	AG2520	3	N	N
PANASONIC	AG2530	3	N	N
PANASONIC	AG2540	3	N	N
PANASONIC	AG2550P	3	N	N
PANASONIC	AG2550P	3	N	N
PANASONIC	AG2550P	3	N	Y
PANASONIC	AG2560	3	N	Y
PANASONIC	AG2600E	3	N	N
PANASONIC	AG513	9	N	Y
PANASONIC	AG5200P	3	N	N
PANASONIC	AG5210	4	N	N
PANASONIC	AG5700P	3	N	Y
PANASONIC	AG5710P	3	N	Y
PANASONIC	AG6010S	3	N	N
PANASONIC	AG6024	3	N	Y
PANASONIC	AG6030	3	N	N
PANASONIC	AG6040	3	N	N
PANASONIC	AG6100	4	N	N
PANASONIC	AG6124	4	N	Y
PANASONIC	AG6200	4	N	N
PANASONIC	AG6720	3	N	N
PANASONIC	AG6730	3	N	N
PANASONIC	AG6740	3	N	N
PANASONIC	AG6810	4	N	N
PANASONIC	AG6850H	4	N	N
PANASONIC	AG7110	4	N	N
PANASONIC	AG7150	4	N	N
PANASONIC	AG7300	4	N	N
PANASONIC	AG7330E	4	N	N
PANASONIC	AG7350	4	N	N
PANASONIC	AG810	2	N	N
PANASONIC	AG810P	2	N	N
PANASONIC	AGB11	2	N	N

PANASONIC	AGEP80	3	N	Y
PANASONIC	AGES100	2	N	N
PANASONIC	AGLD20	4	N	Y
PANASONIC	AGLD30	3	N	N
PANASONIC	AGRT600	4	N	N
PANASONIC	AGW1	3	N	N
PANASONIC	BT5700N	5	N	N
PANASONIC	BTH1390Y	8	N	Y
PANASONIC	BTS1300N	8	N	N
PANASONIC	BTS700N	6	N	N
PANASONIC	BTS701N	6	N	N
PANASONIC	BTS901Y	6	N	N
PANASONIC	CT1030M	7	N	N
PANASONIC	CT1330M	9	N	N
PANASONIC	CT1330V	9	N	N
PANASONIC	CT1331Y	9	N	N
PANASONIC	CT1381	8	N	Y
PANASONIC	CT1382VY	8	N	Y
PANASONIC	CT1383VY	8	N	Y
PANASONIC	CT1383Y	8	N	Y
PANASONIC	CT1384VY	8	N	Y
PANASONIC	CT1386VY	3	N	N
PANASONIC	CT1386VY	8	N	Y
PANASONIC	CT1386Y	8	N	Y
PANASONIC	CT13R14U	8	N	Y
PANASONIC	CT13R16	8	N	Y
PANASONIC	CT1400MG	9	N	N
PANASONIC	CT9R20T	7	N	Y
PANASONIC	CTP1351R	8	N	Y
PANASONIC	CTS1390Y	8	N	N
PANASONIC	DT1300MS	9	N	Y
PANASONIC	DVDA100	3	N	N
PANASONIC	DVDA110	3	N	N
PANASONIC	DVDA300	3	N	N
PANASONIC	DVDA310	3	N	N
PANASONIC	DVDT2000	3	N	N
PANASONIC	E93251	2	N	Y
PANASONIC	FZ1	3	N	Y
PANASONIC	LX121	3	N	N
PANASONIC	LX200	3	N	N
PANASONIC	LX600	4	N	N
PANASONIC	LX900U	3	N	N
PANASONIC	LXH670U	4	N	N
PANASONIC	LXH680	4	N	N
PANASONIC	LXK770	4	N	N
PANASONIC	NV8950	4	Y	N
PANASONIC	NVG39PX	3	N	N
PANASONIC	NVG50PX	3	N	Y
PANASONIC	NVW1	3	N	N
PANASONIC	PV1360	3	N	Y
PANASONIC	PV1642	3	N	N
PANASONIC	PV2912	3	N	N

PANASONIC	PV4010	3	N	N
PANASONIC	PV4066	3	N	N
PANASONIC	PV4068	3	N	N
PANASONIC	PV4114	3	N	Y
PANASONIC	PV4160	3	N	Y
PANASONIC	PV4210	3	N	Y
PANASONIC	PV4250	3	N	Y
PANASONIC	PV4260	3	N	Y
PANASONIC	PV4262	3	N	Y
PANASONIC	PV4361	3	N	Y
PANASONIC	PV4362	3	N	N
PANASONIC	PV4401	3	N	N
PANASONIC	PV4451	3	N	N
PANASONIC	PV4461	3	N	Y
PANASONIC	PV4462	3	N	Y
PANASONIC	PV4464	3	N	N
PANASONIC	PV4501	3	N	Y
PANASONIC	PV4562	3	N	Y
PANASONIC	PV4601	3	N	Y
PANASONIC	PV4661	3	N	Y
PANASONIC	PV4662	3	N	Y
PANASONIC	PV4760	3	N	N
PANASONIC	PV4860	3	N	N
PANASONIC	PV4960	3	N	N
PANASONIC	PV7400	3	N	Y
PANASONIC	PV7450	3	N	Y
PANASONIC	PV7451	3	N	Y
PANASONIC	PV7664	3	N	N
PANASONIC	PV8400	3	N	Y
PANASONIC	PV8450	3	N	Y
PANASONIC	PV8451	3	N	Y
PANASONIC	PV8661	3	N	N
PANASONIC	PVMP10	3	N	Y
PANASONIC	PVS4167	3	N	N
PANASONIC	PVS4266	3	N	N
PANASONIC	PVS4366	3	N	N
PANASONIC	PVS4380	3	N	N
PANASONIC	PVS4480	3	N	N
PANASONIC	PVS4566	3	N	Y
PANASONIC	PVS4580	3	N	N
PANASONIC	PVS4670	3	N	Y
PANASONIC	PVS4690	3	N	N
PANASONIC	PVS4864	2	N	N
PANASONIC	PVS4980	3	N	N
PANASONIC	PVS4986	3	N	N
PANASONIC	PVS7670	3	N	N
PANASONIC	PVS7680	3	N	Y
PANASONIC	PVVP1	3	N	N
PANASONIC	PXVP1	3	N	N
PANASONIC	SGD16	7	N	N
PANASONIC	SL4300	2	N	N
PANASONIC	SLPJ316	3	N	N

PANASONIC	ST900Y	6	N	N
PANASONIC	SV3200	3	N	N
PANASONIC	SV3700	3	N	N
PANASONIC	TR124M	7	N	N
PANASONIC	TR930	6	N	N
PANASONIC	TR930B	6	N	N
PANASONIC	TUIRD10	2	N	N
PANASONIC	TV1012	2	N	N
PANASONIC	TZPC1750GB2	2	N	N
PANASONIC	WACM1000	6	N	Y
PANASONIC	WJ450	3	N	N
PANASONIC	WV5200B	5	N	N
PANASONIC	WV5200BU	4	N	N
PANASONIC	WV5370	6	N	Y
PANASONIC	WV5380A	6	N	N
PANASONIC	WV7330	3	N	N
PANASONIC	WVBM1400	8	N	Y
PANASONIC	WVCM1000	6	N	Y
PANASONIC	WVCR12	3	N	N
PANASONIC	WVRC35	3	N	N
PANASONIC	WVRM70	2	N	N
PARADIGM	X30	2	N	N
PARASOUND	CDC1500	3	N	Y
PARASOUND	HCA500	3	N	N
PARASOUND	REQ150	2	N	Y
PARASOUND	TDQ1600	3	N	Y
PARKER	6201	4	N	Y
PARKERVISION	CAMERAMAN MDS2000SERIESII	2	N	N
PEAK	390800	2	N	N
PEAVEY	UM10	3	N	N
PELCO	MPTA24DT	2	N	N
PENTAGON	CP4010	4	N	N
PERREAUX	MC6100	5	N	N
PERREAUX	PMF1050	3	N	N
PERREAUX	SX1	2	N	N
PETRAS	DS100	3	N	N
PHAST	SEE AMX	2	N	N
PHILIPS	AV1002	4	N	N
PHILIPS	AV101	4	N	N
PHILIPS	CD1220	3	N	N
PHILIPS	CD920	3	N	Y
PHILIPS	CD921	3	N	Y
PHILIPS	CDC875	3	N	N
PHILIPS	CDC916	3	N	Y
PHILIPS	CDC925	3	N	Y
PHILIPS	CDC926	3	N	Y
PHILIPS	CDI220	3	N	N
PHILIPS	CDI490	3	N	N
PHILIPS	CDI615	3	N	N
PHILIPS	CDI910	3	N	N
PHILIPS	CDR765	3	N	N
PHILIPS	CDR870	3	N	Y

PHILIPS	CDV400	4	N	N
PHILIPS	CDV488	3	N	N
PHILIPS	DCC900	4	N	Y
PHILIPS	DVD400AT	2	N	N
PHILIPS	DVX8000	5	N	N
PHILIPS	FA860	4	N	N
PHILIPS	FA950	4	N	Y
PHILIPS	FC40	4	N	N
PHILIPS	FC415	4	N	N
PHILIPS	FC566	3	N	N
PHILIPS	FC911	4	N	Y
PHILIPS	FC930	4	N	Y
PHILIPS	FR910	4	N	Y
PHILIPS	FT50	3	N	N
PHILIPS	FT565	2	N	N
PHILIPS	FT920	3	N	Y
PHILIPS	LTC3924/60	3	N	Y
PHILIPS	PB5013C121	8	N	N
PHILIPS	PB7013C121	8	N	Y
PHILIPS	PHILLIPS	3	N	Y
PHILIPS	PM3251	6	N	N
PHILIPS	RV450	2	N	N
PHILIPS	VCR100BK	3	N	Y
PHILIPS	VPH733TS01	3	N	N
PHILIPS	VR6595AT02	3	N	Y
PHILIPS	VR6605	3	N	N
PHILIPS	VR6615	3	N	Y
PHILIPS	VR6615AT01	3	N	Y
PHILIPS	VR6695AT01	3	N	Y
PHILIPS	VR6785	3	N	N
PHILIPS	VRX242AT02	3	N	Y
PHILIPS	VRX342AT22	3	N	Y
PHILIPS	VRZ224AT	3	N	Y
PHILIPS	VRZ360AT	3	N	N
PICO	AB4	2	N	N
PINNACLE	101871	3	N	Y
PINNACLE	WY670	8	N	Y
PIONEER	BT1370	2	N	N
PIONEER	C72	4	N	Y
PIONEER	C90	3	N	N
PIONEER	CLD1010	3	N	N
PIONEER	CLD1030	3	N	N
PIONEER	CLD1070	3	N	N
PIONEER	CLD1090	3	N	N
PIONEER	CLD2070	4	N	N
PIONEER	CLD2080	4	N	N
PIONEER	CLD2090	4	N	N
PIONEER	CLD3030	3	N	N
PIONEER	CLD3070	4	N	N
PIONEER	CLD3080	4	N	Y
PIONEER	CLD3090	4	N	N
PIONEER	CLD52	4	N	N

PIONEER	CLD53	4	N	N
PIONEER	CLD59	4	N	N
PIONEER	CLD79	4	N	N
PIONEER	CLD8380	3	N	N
PIONEER	CLD909	3	N	N
PIONEER	CLD91	4	N	N
PIONEER	CLD92	4	N	N
PIONEER	CLD95	4	N	N
PIONEER	CLD97	5	N	N
PIONEER	CLD980	3	N	N
PIONEER	CLD99	4	N	N
PIONEER	CLDA100	4	N	N
PIONEER	CLDD406	4	N	N
PIONEER	CLDD501	4	N	N
PIONEER	CLDD502	4	N	N
PIONEER	CLDD503	4	N	N
PIONEER	CLDD504	4	N	N
PIONEER	CLDD505	4	N	N
PIONEER	CLDD605	4	N	N
PIONEER	CLDD701	4	N	N
PIONEER	CLDD702	4	N	N
PIONEER	CLDD703	4	N	N
PIONEER	CLDD704	4	N	N
PIONEER	CLDM301	4	N	N
PIONEER	CLDM401	4	N	N
PIONEER	CLDM90	4	N	N
PIONEER	CLDS201	3	N	N
PIONEER	CLDS304	3	N	N
PIONEER	CLDV101	4	N	Y
PIONEER	CLDV121G	3	N	N
PIONEER	CLDV2400	3	N	N
PIONEER	CLDV2600	3	N	N
PIONEER	CLDV2800	4	N	N
PIONEER	CLDV303T	6	N	N
PIONEER	CLDV5000	4	N	N
PIONEER	CLDV510	4	N	N
PIONEER	CLDV704	4	N	N
PIONEER	CLDV710	4	N	N
PIONEER	CLDV720	4	N	Y
PIONEER	CLDV820	4	N	Y
PIONEER	CLDV840	4	N	N
PIONEER	CLDV850	4	N	N
PIONEER	CLDV860	4	N	N
PIONEER	CLDV870	4	N	N
PIONEER	CLDV880	4	N	N
PIONEER	COV200	3	N	Y
PIONEER	CT05D	3	N	Y
PIONEER	CT07D	3	N	Y
PIONEER	CT1170W	3	N	N
PIONEER	CT1380WR	3	N	N
PIONEER	CT40	3	N	N
PIONEER	CT43	4	N	N

PIONEER	CT50R	3	N	N
PIONEER	CT93	4	N	N
PIONEER	CTF900	5	N	N
PIONEER	CTM66R	4	N	N
PIONEER	CTM6R	4	N	N
PIONEER	CTS609R	4	N	N
PIONEER	CTS800	4	N	N
PIONEER	CTV70	3	N	N
PIONEER	CTW1370	3	N	Y
PIONEER	CTW301	3	N	N
PIONEER	CTW351R	3	N	N
PIONEER	CTW402R	3	N	N
PIONEER	CTW430	3	N	N
PIONEER	CTW450R	3	N	N
PIONEER	CTW451	3	N	N
PIONEER	CTW502R	3	N	N
PIONEER	CTW503R	3	N	N
PIONEER	CTW504R	4	N	N
PIONEER	CTW505R	4	N	N
PIONEER	CTW51	4	N	N
PIONEER	CTW53	4	N	N
PIONEER	CTW530R	3	N	N
PIONEER	CTW54	3	N	N
PIONEER	CTW550R	3	N	N
PIONEER	CTW59	3	N	N
PIONEER	CTW601R	4	N	N
PIONEER	CTW602R	3	N	N
PIONEER	CTW603RS	4	N	N
PIONEER	CTW604RS	3	N	N
PIONEER	CTW616DR	3	N	
PIONEER	CTW700R	3	N	N
PIONEER	CTW704RS	4	N	N
PIONEER	CTW710R	3	N	N
PIONEER	CTW79	3	N	N
PIONEER	CTW850R	4	N	N
PIONEER	CTW900R	4	N	N
PIONEER	CTW910R	4	N	N
PIONEER	CTWM62R	4	N	N
PIONEER	CTWM70R	4	N	N
PIONEER	CTWM77R	4	N	N
PIONEER	DV09	4	N	N
PIONEER	DV414	3	N	N
PIONEER	DV500	3	N	N
PIONEER	DV505	3	N	N
PIONEER	DV606D	3	N	N
PIONEER	DVDV7200	3	N	N
PIONEER	DVL700	4	N	N
PIONEER	DVL90	4	N	N
PIONEER	DVL909	4	N	N
PIONEER	DVL91	4	N	N
PIONEER	DVLV888	4	N	N
PIONEER	F449	3	N	N

PIONEER	F51	3	N	N
PIONEER	F551	2	N	N
PIONEER	F656	3	N	N
PIONEER	F91	3	N	N
PIONEER	F99X	2	N	N
PIONEER	GR777	3	N	N
PIONEER	HR99	4	N	N
PIONEER	LD700	3	N	N
PIONEER	LD870	3	N	N
PIONEER	LDLKV350	3	Y	N
PIONEER	LDS2	5	N	N
PIONEER	LDV2000	3	N	N
PIONEER	LDV2200	3	N	N
PIONEER	LDV4200	3	N	N
PIONEER	LDV4400	3	N	Y
PIONEER	LDV6000A	4	N	N
PIONEER	LDV8000	4	N	N
PIONEER	LDW1	4	N	N
PIONEER	LKV350	4	Y	N
PIONEER	M72	4	N	N
PIONEER	M90	4	N	Y
PIONEER	MA9	3	N	N
PIONEER	ORM624	3	N	N
PIONEER	PD 103	3	N	N
PIONEER	PD-59	3	N	N
PIONEER	PD101	3	N	N
PIONEER	PD203	3	N	N
PIONEER	PD4350	3	N	N
PIONEER	PD4500	3	N	N
PIONEER	PD5010	3	N	N
PIONEER	PD5100	3	N	N
PIONEER	PDAP1	3	N	N
PIONEER	PDDM802	4	N	N
PIONEER	PDDM902	4	N	N
PIONEER	PDF07	5	N	N
PIONEER	PDF100	5	N	N
PIONEER	PDF1004	5	N	N
PIONEER	PDF1005	5	N	N
PIONEER	PDF1006	5	N	N
PIONEER	PDF107	5	N	N
PIONEER	PDF109	5	N	N
PIONEER	PDF407	5	N	N
PIONEER	PDF505	5	N	N
PIONEER	PDF507	5	N	N
PIONEER	PDF59	5	N	N
PIONEER	PDF805	5	N	N
PIONEER	PDF904	5	N	N
PIONEER	PDF905	5	N	N
PIONEER	PDF906	5	N	N
PIONEER	PDF957	5	N	N
PIONEER	PDM3	4	N	N
PIONEER	PDM400	3	N	N

PIONEER	PDM403	3	N	N
PIONEER	PDM410	3	N	N
PIONEER	PDM423	3	N	N
PIONEER	PDM426	3	N	N
PIONEER	PDM430	3	N	N
PIONEER	PDM435	3	N	N
PIONEER	PDM50	2	N	N
PIONEER	PDM500	3	N	N
PIONEER	PDM501	3	N	N
PIONEER	PDM502	3	N	N
PIONEER	PDM510	3	N	N
PIONEER	PDM53	4	N	N
PIONEER	PDM530	3	N	N
PIONEER	PDM550	3	N	N
PIONEER	PDM552	3	N	N
PIONEER	PDM59	3	N	N
PIONEER	PDM6	3	N	N
PIONEER	PDM60	3	N	N
PIONEER	PDM601	3	N	N
PIONEER	PDM603	3	N	N
PIONEER	PDM610	3	N	N
PIONEER	PDM630	3	N	N
PIONEER	PDM650	4	N	N
PIONEER	PDM70	3	N	N
PIONEER	PDM700	3	N	N
PIONEER	PDM701	4	N	N
PIONEER	PDM702	3	N	N
PIONEER	PDM703	3	N	N
PIONEER	PDM710	3	N	N
PIONEER	PDM730	3	N	N
PIONEER	PDM77	4	N	N
PIONEER	PDM801	4	N	N
PIONEER	PDM900	3	N	N
PIONEER	PDM901	4	N	N
PIONEER	PDM95	4	N	N
PIONEER	PDR05	4	N	N
PIONEER	PDR99	4	N	N
PIONEER	PDTM1	5	N	N
PIONEER	PDTM2	5	N	N
PIONEER	PDTM3	5	N	N
PIONEER	PDV10G	3	N	N
PIONEER	PL910	3	N	N
PIONEER	PLV70	3	N	N
PIONEER	RT1050	10	N	N
PIONEER	SAV220	4	N	Y
PIONEER	SAV240	4	N	Y
PIONEER	SP700D	3	N	N
PIONEER	SP91D	3	N	N
PIONEER	SP99D	3	N	N
PIONEER	SR303	3	N	N
PIONEER	SX1300	3	N	N
PIONEER	SX1900	3	N	N

PIONEER	SX205	4	N	N
PIONEER	SX2300	3	N	N
PIONEER	SX255R	4	N	N
PIONEER	SX31	4	N	N
PIONEER	SX312R	4	N	N
PIONEER	SX424	4	N	N
PIONEER	TVX9500	3	N	N
PIONEER	TX970	2	N	N
PIONEER	TXV1160	2	N	N
PIONEER	TXV70	2	N	N
PIONEER	UCV102	4	N	N
PIONEER	VH600	3	N	N
PIONEER	VH900	3	N	N
PIONEER	VSA1000	4	N	N
PIONEER	VSX07TX	5	N	Y
PIONEER	VSX09TX	5	N	Y
PIONEER	VSX3600	3	N	N
PIONEER	VSX401	3	N	N
PIONEER	VSX453	4	N	N
PIONEER	VSX49	4	N	Y
PIONEER	VSX5000	3	N	N
PIONEER	VSX504S	4	N	Y
PIONEER	VSX511S	4	N	N
PIONEER	VSX52	4	N	N
PIONEER	VSX53	4	N	Y
PIONEER	VSX5300	3	N	N
PIONEER	VSX59	4	N	Y
PIONEER	VSX79	4	N	Y
PIONEER	VSX9500	4	N	N
PIONEER	VSX9700S	4	N	N
PIONEER	VSX99	4	N	N
PIONEER	VSX9900S	4	N	N
PIONEER	VSXD1S	4	N	Y
PIONEER	VSXD901S	4	N	N
PIONEER	VSXD902S	4	N	N
PIONEER	VSXD906S	5	N	N
PIXIE	PBC1564	8	N	Y
POWER COM.	PCM	9	N	Y
PRESTIQE	0650P1	4	N	N
PRIMESTAR	300D	3	N	N
PRIMESTAR	301D	3	N	Y
PRINCETON	HX12RGB	7	N	Y
PRINCETON	HX9	6	N	N
PRINCETON	ULTRA 40	9	N	Y
PROCEED	AMP2(FACE ONLY)	3	N	Y
PROCEED	AMP5	3	N	Y
PROCEED	AMP5	4	Y	Y
PROCEED	AVP	4	Y	Y
PROCEED	CDD	3	N	Y
PROCEED	PAV	3	N	Y
PROCEED	PDSO	3	N	Y
PROSCAN	PRD8630A	2	N	N

PROSCAN	PS8600P	2	N	Y
PROSCAN	PS8680Z	2	N	N
PROSCAN	PSLD46	4	N	N
PROSCAN	PSVR61	3	N	Y
PROSCAN	PSVR62	3	N	Y
PROSCAN	PSVR63	3	N	N
PROSCAN	PSVR65	3	N	N
PROSCAN	PSVR74	3	N	Y
PROSCAN	PSVR80	3	N	N
PROSCAN	PSVR81	3	N	Y
PROSCAN	PSVR83	3	N	N
PROTEK	B820	3	N	Y
PROTON	1100	2	N	N
PROTON	440	2	N	N
PROTON	600T	3	N	N
PROTON	601T	2	N	N
PROTON	740	3	N	N
PROTON	830R	3	N	N
PROTON	AA1150	3	N	N
PROTON	AA1660	3	N	N
PROTON	AA2060	4	N	N
PROTON	AD200	3	N	Y
PROTON	AD300	3	N	N
PROTON	AM300	3	N	N
PROTON	AP2000	2	N	N
PROTON	AT300	2	N	N
PROTON	D1200	3	N	N
PROTON	D540	3	N	N
PROTON	D940	3	N	N
PROTON	SD1000	2	N	N
PS AUDIO	250DELTA	4	N	Y
PS AUDIO	6.2AMP	2	N	N
PS AUDIO	DL THREE	2	N	N
PS AUDIO	LAMBDA	3	N	Y
PS AUDIO	PHONOLINK	2	N	Y
PS AUDIO	REF.LINKLS	3	N	Y
PS AUDIO	ULTRALINK	2	N	Y
PS AUDIO	VM900	6	N	Y
QINTAR	4004B	2	N	N
QUASAR	DYNACOLOR	9	N	N
QUASAR	TP1315J	8	N	Y
QUASAR	VH200	3	N	Y
QUASAR	VH400	3	N	N
QUASAR	VH434	3	N	Y
QUASAR	VH5485	3	N	N
QUASAR	VH5675	3	N	N
QUASAR	VH5975	3	N	N
QUASAR	VH6405	3	N	N
QUASAR	VH6505	3	N	N
QUASAR	VHQ540	3	N	Y
QUIMAX	DM14	8	N	N
QUIMAX	DX14	8	N	N

QUME	QM835	8	N	Y
QUME	QVT31	8	N	Y
RAD	ASM40	2	N	N
RADIO SHACK	15-1956	2	N	Y
RADIO SHACK	PRO2026	2	N	N
RADIO SHACK	PRO2042	3	N	Y
RANE	THX44	3	Y	N
RBH	SAM200	3	N	N
RBH	TA350	3	N	N
RCA	DRD102RW	2	N	Y
RCA	DRD203RW	2	N	Y
RCA	DRD212NW	2	N	Y
RCA	DRD302 RA	2	N	N
RCA	DRD303RA	2	N	N
RCA	DRD403RA	2	N	N
RCA	DRD503RBC	2	N	N
RCA	DRD505RA	2	N	N
RCA	DRD505RB	2	N	N
RCA	DRD515RB	2	N	N
RCA	DRD523RB	2	N	N
RCA	DRD703RA	2	N	N
RCA	DXD402RA	2	N	N
RCA	E13202WT	8	N	Y
RCA	E13332BC	8	N	Y
RCA	LDR310	3	N	N
RCA	LDR400	4	N	N
RCA	LDR500	4	N	N
RCA	NRD412	2	N	N
RCA	RBH	3	N	N
RCA	RC5500P	2	N	N
RCA	RC5510P	2	N	N
RCA	RP8593	7	N	N
RCA	TC1100	6	N	Y
RCA	TC1112	7	N	N
RCA	TC3920	3	N	N
RCA	VMT630HF	3	N	N
RCA	VR250	3	N	Y
RCA	VR290	3	N	Y
RCA	VR301	3	N	Y
RCA	VR327	3	N	Y
RCA	VR500	3	N	Y
RCA	VR503	3	N	Y
RCA	VR522	3	N	N
RCA	VR540	3	N	N
RCA	VR601HF	3	N	Y
RCA	VR605	3	N	Y
RCA	VR615HF	3	N	N
RCA	VR619HF	3	N	Y
RCA	VR621HF	3	N	Y
RCA	VR640HF	3	N	N
RCA	VR652	3	N	N
RCA	VR667HF	3	N	Y

RCA	VR673HF	3	N	Y
RCA	VR678	3	N	N
RCA	VR688HF	3	N	N
RCA	VR692HF	3	N	N
RCA	VR725	3	N	Y
RCA	VR730HF	2	N	Y
RCA	VR730HF	3	N	Y
RCA	VR911HF	3	N	N
REALISTIC	20144	2	N	N
REALISTIC	APM200	3	N	N
REALISTIC	AV900	3	N	Y
REALISTIC	CD1500	2	N	N
REALISTIC	CD6000	3	N	N
REALISTIC	MINIMUS 3.5	3	N	Y
REALISTIC	MPA25	3	N	N
REALISTIC	SCT74	3	N	N
REALISTIC	SCT80	3	N	N
REALISTIC	SCT86	3	N	N
REF. AUDIO DESIGN	MS2	2	N	Y
REGAL	II	2	N	Y
RIC	DL1564M	8	N	Y
ROLAND	AR100	2	N	N
ROR	MONITOR	4	N	N
ROTEL	RB850	3	N	N
ROTEL	RB870BX	3	N	N
ROTEL	RB930AX	3	N	N
ROTEL	RB956AX	3	N	N
ROTEL	RB960BX	3	N	N
ROTEL	RB970BX	3	N	N
ROTEL	RB971	3	N	N
ROTEL	RB980BX	3	N	N
ROTEL	RB985	4	N	N
ROTEL	RCC935	3	Y	N
ROTEL	RCC940AX	3	N	N
ROTEL	RCC945	3	N	N
ROTEL	RCD965BX	3	N	N
ROTEL	RD960BX	3	N	N
ROTEL	RDA975	3	N	N
ROTEL	RDA980	2	N	N
ROTEL	RDP9800	3	N	N
ROTEL	RLC900	2	N	N
ROTEL	RMB100	5	N	N
ROTEL	RMZ950	3	N	N
ROTEL	RQ970BX	2	N	N
ROTEL	RSP960AX	3	N	N
ROTEL	RSP980	3	N	N
ROTEL	RT850A	2	N	N
ROTEL	RT940	2	N	N
ROTEL	RTC940ax	3	N	N
ROTEL	RTC970	3	N	N
ROTEL	RX950AX	3	N	N
ROWE	CPC180	7	N	N

RUNCO	ARC4	2	N	N
RUNCO	SAR CONTROL	4	Y	N
RUNCO	SAR200	6	Y	Y
RUNCO	SC1050	3	N	N
RUNCO	SC2050	3	N	N
RUNCO	SC3050	3	N	N
RUSSOUND	AX6	2	N	N
RUSSOUND	PRO12HP	2	N	N
RUSSOUND	PRO6	3	N	N
RUSSOUND	SC12	3	N	N
RUSSOUND	SDB4EZ	2	N	N
RUSSOUND	SS4	2	N	N
RUSSOUND	SS6	2	N	N
RUSSOUND	SSAB	2	N	N
RUSSOUND	TMS10	2	N	N
SAMPO	KM400A	8	N	Y
SAMSON	RH1	2	N	N
SAMSUNG	3000V	4	N	N
SAMSUNG	MZ4571	8	N	Y
SAMSUNG	SV300W	3	N	N
SAMSUNG	SV4000W	3	N	N
SAMSUNG	TXD1372	8	N	Y
SAMSUNG	VR8704	3	N	Y
SAMSUNG	VR8756	3	N	Y
SAMTRON	8514	8	N	Y
SANSUI	CD390M	3	N	N
SANSUI	CDV350	2	N	N
SANSUI	CDX510U	4	N	N
SANSUI	CDX711	4	N	N
SANSUI	D590R	3	N	N
SANSUI	D69	3	N	N
SANSUI	D75BW	3	N	N
SANSUI	D75CW	3	N	N
SANSUI	DW11	3	N	N
SANSUI	DX301	3	N	N
SANSUI	R550	4	N	N
SANSUI	SE510	2	N	N
SANSUI	TUD99X	2	N	N
SANYO	RDW40D	4	N	N
SANYO	SRT600	3	N	Y
SANYO	VCR4020	3	N	N
SANYO	VHR2900	3	N	N
SANYO	VHR9413A	3	N	N
SAT N SOUND	AE6000	2	N	Y
SCI.ATLANTIC	852830001	2	N	N
SCI.ATLANTIC	85293	2	N	N
SCI.ATLANTIC	8535430	2	N	N
SCI.ATLANTIC	8550321	2	N	Y
SCI.ATLANTIC	857033701	2	N	Y
SCI.ATLANTIC	8580	2	N	Y
SCI.ATLANTIC	8580	2	N	N
SCI.ATLANTIC	8580338	2	N	N

SCI.ATLANTIC	8582	2	N	Y
SCI.ATLANTIC	8600	2	N	Y
SCI.ATLANTIC	9700	3	N	N
SCI.ATLANTIC	DM2000	2	N	N
SCI.ATLANTIC	SERIES8500	2	N	N
SCI.ATLANTIC	VU9234	2	N	N
SCOOTER	ABC8	2	N	N
SCOTT	686DD	4	N	N
SCOTT	DA980	2	N	N
SEA TEL	TAC92C	3	Y	Y
SENNHEISER	SI1013	2	N	Y
SENSORMATIC	RVTLR24B	3	N	N
SERVOWATCH	B111	3	N	N
SHARP	13FM100	8	N	Y
SHARP	13MM17	8	N	N
SHARP	5GII	4	N	N
SHARP	DX110	2	N	N
SHARP	DX111	2	N	N
SHARP	DX650	2	N	N
SHARP	DXC1800	3	N	N
SHARP	DXC6000	3	N	N
SHARP	MVD100BK	4	N	N
SHARP	RP119	3	N	N
SHARP	RT1157	4	N	N
SHARP	RT3388A	4	Y	N
SHARP	RT360	3	N	N
SHARP	RTW800	3	N	N
SHARP	SXD100	3	N	N
SHARP	VC683U	3	N	N
SHARP	VC780E	3	N	N
SHARP	VC90ET	3	N	Y
SHARP	VCA205	3	N	Y
SHARP	VCA542U	3	N	Y
SHARP	VCA544	3	N	Y
SHARP	VCA5640U	3	N	Y
SHARP	VCA564G	3	N	Y
SHARP	VCG975U	3	N	N
SHARP	VCG980	3	N	N
SHARP	VCG990	3	N	Y
SHARP	VCH85U	3	N	N
SHARP	VCH907U	3	N	N
SHARP	VCH973	3	N	N
SHARP	VCMH80	3	N	Y
SHARP	VCMH83	3	N	Y
SHARP	VCNX1	3	N	Y
SHARP	VCQ77U	3	N	N
SHARP	VCWD1	3	N	Y
SHARP	XA100	3	N	Y
SHARP	XA110	3	N	N
SHARP	XA120	3	N	N
SHARP	XA200	3	N	N
SHARP	XA205	3	N	N

SHARP	XA2500S	4	N	N
SHARP	XA305	3	N	N
SHARP	XA310	3	N	N
SHARP	XA405	3	N	N
SHARP	XA505	3	N	Y
SHARP	XA510	3	N	Y
SHARP	XA520	3	N	Y
SHARP	XA605	3	N	Y
SHARP	XA610	3	N	Y
SHARP	XA620	3	N	Y
SHARP	XA705	3	N	N
SHARP	XA720	3	N	Y
SHERWOOD	CDC6050R	3	N	N
SHERWOOD	CDC680T	3	N	N
SHERWOOD	DD1030	4	N	N
SHERWOOD	DD980T	4	N	N
SHERWOOD	R945	4	N	N
SHERWOOD	RX2050R	3	N	N
SHURE	HTS5000	2	N	N
SHURE	HTS5200	2	N	N
SHURE	M68FCA	2	N	N
SHURE	MQ50	2	N	N
SHURE	PROLOGUE200M	2	N	N
SHURE	SV40	3	N	N
SIEMENS	V72	2	N	N
SMILE	CB6736SL	9	N	Y
SOCOS	MA1450	8	N	Y
SONANCE	2120	4	N	N
SONANCE	AC1	3	N	N
SONANCE	ASAP1	2	N	N
SONANCE	MRC100	3	N	N
SONANCE	SDS6	2	N	N
SONANCE	SONAMP260X3	3	N	N
SONY	CDPC205	3	N	N
SONY	CDPC225	3	N	N
SONY	CDPC245	3	N	N
SONY	CDPC265	3	N	N
SONY	CDPC30	3	N	N
SONY	CDPC305	3	N	N
SONY	CDPC321	3	N	N
SONY	CDPC331	3	N	N
SONY	CDPC345	3	N	N
SONY	CDPC365	3	N	N
SONY	CDPC425	3	N	N
SONY	CDPC445	3	N	N
SONY	CDPC450Z	3	N	Y
SONY	CDPC50	3	N	N
SONY	CDPC500	3	N	N
SONY	CDPC505	3	N	N
SONY	CDPC515	3	N	N
SONY	CDPC525	3	N	N
SONY	CDPC535	3	N	N

SONY	CDPC545	3	N	N
SONY	CDPC5F	3	N	N
SONY	CDPC601ES	3	N	N
SONY	CDPC67ES	3	N	N
SONY	CDPC69ES	3	N	N
SONY	CDPC700	3	N	N
SONY	CDPC701ES	3	N	N
SONY	CDPC705	3	N	N
SONY	CDPC735	3	N	N
SONY	CDPC745	3	N	N
SONY	CDPC75ES	3	N	N
SONY	CDPC77ES	3	N	N
SONY	CDPC79ES	3	N	N
SONY	CDPC7ESD	3	N	N
SONY	CDPC800	3	N	N
SONY	CDPC85ES	3	N	N
SONY	CDPC87ES	3	N	N
SONY	CDPC89ES	3	N	N
SONY	CDPC8ESD	3	N	N
SONY	CDPC900	3	N	N
SONY	CDPC90ES	3	N	N
SONY	CDPC910	3	N	N
SONY	CDPC9ESD	3	N	N
SONY	CDPCA7ES	3	N	Y
SONY	CDPCA80ES	3	N	Y
SONY	CDPCA8ES	3	N	Y
SONY	CDPCA9ES	3	N	Y
SONY	CDPCE215	3	N	Y
SONY	CDPCE305	3	N	Y
SONY	CDPCE315	3	N	Y
SONY	CDPCE405	3	N	Y
SONY	CDPCE415	3	N	Y
SONY	CDPCE505	3	N	Y
SONY	CDPCE515	3	N	Y
SONY	CDPCE525	3	N	Y
SONY	CDPCX100	6	N	Y
SONY	CDPCX151	6	N	Y
SONY	CDPCX153	5	N	Y
SONY	CDPCX200	5	N	Y
SONY	CDPCX205	5	N	Y
SONY	CDPCX210	5	N	Y
SONY	CDPCX220	5	N	Y
SONY	CDPCX240	5	N	Y
SONY	CDPCX250	5	N	Y
SONY	CDPCX255	3	N	N
SONY	CDPCX255	5	N	Y
SONY	CDPCX260	5	N	Y
SONY	CDPCX270	5	N	Y
SONY	CDPCX53	5	N	Y
SONY	CDPCX55	5	N	Y
SONY	CDPCX70ES	5	N	Y
SONY	CDPCX90ES	5	N	Y

SONY	CDPK1	3	N	N
SONY	CDPL601ES	3	N	N
SONY	CDPX111ES	3	N	N
SONY	CDPX202ES	3	N	N
SONY	CDPX229ES	3	N	N
SONY	CDPX33ES	3	N	N
SONY	CDPX55ES	3	N	N
SONY	CDPX777ES	3	N	N
SONY	CDPXA1ES	3	N	N
SONY	CDPXA1ES	3	N	N
SONY	CDPXA20ES	3	N	Y
SONY	CDPXA20ES	3	N	N
SONY	CDPXE400	3	N	Y
SONY	CDPXE500	3	N	Y
SONY	CDV1000	3	N	N
SONY	CDX505RF	3	N	Y
SONY	CMA10	3	N	N
SONY	CMA8	3	N	N
SONY	CPD100SF	9	N	Y
SONY	CPD121	7	N	Y
SONY	CPD1302	9	N	Y
SONY	CPD1304	8	N	Y
SONY	CPD1320	8	N	Y
SONY	CPD1425	9	N	Y
SONY	CPD1430	8	N	Y
SONY	CPD17SF	10	N	Y
SONY	CPD200SF	10	N	Y
SONY	CTRL300	3	N	N
SONY	CVM1270	8	N	Y
SONY	CVPG700	3	N	N
SONY	DHR1000	4	N	Y
SONY	DLSL1	3	N	N
SONY	DLSM1	3	N	Y
SONY	DSC 1024	2	N	N
SONY	DSR30	4	N	Y
SONY	DTC1000ES	3	N	N
SONY	DTC300ES	3	N	N
SONY	DTC500ES	3	N	N
SONY	DTC55ES	3	N	N
SONY	DTC59ES	3	N	Y
SONY	DTC60ES	3	N	Y
SONY	DTC670	3	N	N
SONY	DTC690	3	N	N
SONY	DTC700	3	N	N
SONY	DTC75ES	3	N	N
SONY	DTC790	3	N	N
SONY	DTC87ES	4	N	N
SONY	DTCA7	4	N	N
SONY	DTCM100	3	N	N
SONY	DTCZA5ES	3	N	Y
SONY	DTCZE700	3	N	N
SONY	DVPC600D	3	N	Y

SONY	DVPS300	3	N	Y
SONY	DVPS3000	3	N	Y
SONY	DVPS500D	3	N	Y
SONY	DVPS500D	3	N	N
SONY	DVPS7000	3	N	Y
SONY	EDV7500	3	N	N
SONY	EDW30F	4	N	N
SONY	EVA50	2	N	N
SONY	EVC100	2	N	N
SONY	EVC20	2	N	N
SONY	EVC200	3	N	N
SONY	EVC25	2	N	N
SONY	EVC3	3	N	N
SONY	EVO510	3	N	N
SONY	EVO511	3	N	N
SONY	EVO520	3	N	N
SONY	EVO540	2	N	N
SONY	EVO550	2	N	N
SONY	EVO9500A	3	N	N
SONY	EVO9800	4	N	N
SONY	EVP320	3	N	N
SONY	EVS2000	3	N	Y
SONY	EVS3000NTSC	3	N	N
SONY	EVS350	3	N	N
SONY	EVS5000	3	N	N
SONY	EVS550	3	N	N
SONY	EVS7000	3	N	Y
SONY	EVS700U	3	N	N
SONY	EVS800	3	N	N
SONY	EVS900	3	N	Y
SONY	EVT820	3	N	Y
SONY	FDLK400	3	N	Y
SONY	FX160	3	N	N
SONY	FX320520R	3	N	N
SONY	GCS50	3	N	N
SONY	GDM17SE1	10	N	Y
SONY	GDM200PS	9	N	Y
SONY	GVM1300	9	N	N
SONY	GVM1310	9	N	Y
SONY	GVM1311Q	9	N	Y
SONY	GX60ES	4	N	N
SONY	GX67ES	4	N	N
SONY	GX700ES	4	N	N
SONY	GX800ES	4	N	N
SONY	GX900ES	4	N	N
SONY	HCDRX30	8	N	Y
SONY	INT-W100	2	N	N
SONY	INTW200	2	N	Y
SONY	KV1311CR	8	N	N
SONY	KV13M10	8	N	Y
SONY	KV13M20	9	N	Y
SONY	KV13M30	9	N	Y

SONY	KV13M40	9	N	Y
SONY	KV13M50	9	N	Y
SONY	KV13TR20	9	N	N
SONY	KV13TR27	8	N	Y
SONY	KV13TR28	8	N	Y
SONY	KV13V50	8	N	Y
SONY	KV8AD10	5	N	Y
SONY	KV8AD11	5	N	N
SONY	KV9PT20	6	N	Y
SONY	KV9PT60	7	N	Y
SONY	KVG14	8	N	Y
SONY	LDP1450	3	N	N
SONY	LDP1500	3	N	N
SONY	LDP1550	3	N	N
SONY	LVA3500	5	N	N
SONY	LVA7000	5	N	N
SONY	MDP1100	3	N	Y
SONY	MDP1150	3	N	N
SONY	MDP1700AR	3	N	N
SONY	MDP200	3	N	N
SONY	MDP210	3	N	N
SONY	MDP333	3	N	N
SONY	MDP455	3	N	Y
SONY	MDP500	3	N	N
SONY	MDP510	3	N	N
SONY	MDP533D	3	N	N
SONY	MDP600	3	N	N
SONY	MDP605	4	N	N
SONY	MDP650	3	N	N
SONY	MDP700	3	N	N
SONY	MDP800	3	N	N
SONY	MDPK5	4	N	N
SONY	MDPV9K	4	N	Y
SONY	MDS101	2	N	N
SONY	MDS302	3	N	N
SONY	MDS501	3	N	Y
SONY	MDSB3	4	N	N
SONY	MDSB5	4	N	N
SONY	MDSJA3ES	3	N	Y
SONY	MDSJB920	3	N	Y
SONY	MDSJE500	3	N	Y
SONY	MDSJE510	3	N	Y
SONY	MDSJE520	3	N	Y
SONY	MDSJE700	3	N	Y
SONY	MTL10	3	N	N
SONY	MULTISCAN 200SF	10	N	Y
SONY	MVR5600	3	N	N
SONY	PC1270	4	N	N
SONY	PCM2500	2	N	N
SONY	PCM601	3	N	N
SONY	PCM701ES	2	N	N
SONY	PCMR300	3	N	N

SONY	PSFL72	3	N	Y
SONY	PVM1271Q	8	N	N
SONY	PVM1342Q	8	N	N
SONY	PVM1343MD	8	N	N
SONY	PVM1354Q	8	N	N
SONY	PVM1380	9	N	N
SONY	PVM14N1U	8	N	N
SONY	PVM8020	6	N	Y
SONY	PVM8040	6	N	Y
SONY	PVM8041Q	6	N	N
SONY	PVM8220	5	N	N
SONY	PVM8221	6	N	Y
SONY	PVM91	6	N	N
SONY	RMOS350	2	N	N
SONY	RM RTP1	3	N	Y
SONY	SATA1	3	N	N
SONY	SATA2	3	N	N
SONY	SATA3	2	N	Y
SONY	SATA4	2	N	Y
SONY	SATB1	3	N	N
SONY	SATB2	3	N	N
SONY	SATB3	2	N	Y
SONY	SBV1000	3	N	N
SONY	SBV3000	3	N	N
SONY	SBV66S	2	N	N
SONY	SDPE800	3	N	Y
SONY	SDPE800	3	N	N
SONY	SDPEP9ES	3	N	Y
SONY	SEQ711	3	N	N
SONY	SL10	3	N	N
SONY	SL100	3	N	N
SONY	SL2300	2	N	N
SONY	SL2400	2	N	Y
SONY	SL2700	3	N	N
SONY	SL2710	3	N	N
SONY	SL330	3	N	N
SONY	SL340	3	N	N
SONY	SL700ME	3	N	N
SONY	SL800ME	3	N	N
SONY	SLHF1000	3	N	N
SONY	SLHF2000	3	N	N
SONY	SLHF360	3	N	N
SONY	SLHF450	3	N	N
SONY	SLHF900	3	N	Y
SONY	SLO325	4	N	N
SONY	SLO420	2	N	N
SONY	SLV373UC	3	N	Y
SONY	SLV390	3	N	N
SONY	SLV400	3	N	Y
SONY	SLV420	3	N	N
SONY	SLV440	3	N	N
SONY	SLV495	3	N	Y

SONY	SLV555UC	3	N	N
SONY	SLV575UC	3	N	N
SONY	SLV585HF	3	N	Y
SONY	SLV595HF	3	N	N
SONY	SLV640HF	3	N	Y
SONY	SLV660	3	N	Y
SONY	SLV675HF	3	N	Y
SONY	SLV676UC	3	N	Y
SONY	SLV678HF	3	N	Y
SONY	SLV685HF	3	N	N
SONY	SLV686HF	3	N	Y
SONY	SLV688HF	3	N	Y
SONY	SLV690	3	N	Y
SONY	SLV696HF	3	N	Y
SONY	SLV700	3	N	Y
SONY	SLV70HF	3	N	N
SONY	SLV720HF	3	N	N
SONY	SLV740HF	3	N	Y
SONY	SLV750HF	3	N	N
SONY	SLV751	3	N	N
SONY	SLV757UC	3	N	Y
SONY	SLV760	3	N	Y
SONY	SLV765	3	N	Y
SONY	SLV770HF	3	N	N
SONY	SLV775HF	3	N	Y
SONY	SLV778HF	3	N	Y
SONY	SLV780HF	3	N	Y
SONY	SLV788HF	3	N	Y
SONY	SLV790	3	N	Y
SONY	SLV795HF	3	N	Y
SONY	SLV795HF	3	N	N
SONY	SLV798HF	3	N	Y
SONY	SLV900HF	3	N	N
SONY	SLV920HF	3	N	N
SONY	SLV940HF	3	N	Y
SONY	SLV960	3	N	Y
SONY	SLV975HF	3	N	Y
SONY	SLV980	3	N	Y
SONY	SLV998HF	3	N	Y
SONY	SLVK881	3	N	Y
SONY	SLVM10HF	3	N	Y
SONY	SLVM20HF	3	N	Y
SONY	SLVR1000	3	N	Y
SONY	SLVR5UC	3	N	N
SONY	SLVX711	3	N	Y
SONY	SLVX815SG	3	N	Y
SONY	SLVX821	3	N	Y
SONY	SLVX831	3	N	Y
SONY	SLVX842	3	N	Y
SONY	SLVX90	3	N	Y
SONY	SLVX95	3	N	Y
SONY	SPD777ES	3	N	N

SONY	SSM920	6	N	N
SONY	ST72TV	2	N	N
SONY	ST92TV	2	N	N
SONY	STJX401	2	N	N
SONY	STJX431	2	N	N
SONY	STJX661	3	N	Y
SONY	STRAV220	3	N	N
SONY	STRAV770	4	N	N
SONY	STRAV780	4	N	N
SONY	STRAV900	4	N	N
SONY	STRAV910	4	N	N
SONY	STRAV920	4	N	N
SONY	STRD1011	4	N	N
SONY	STRD1011	4	N	N
SONY	STRD1015	4	N	N
SONY	STRD1090	4	N	N
SONY	STRD311	4	N	N
SONY	STRD315	4	N	N
SONY	STRD365	4	N	N
SONY	STRD515	4	N	N
SONY	STRD865	4	N	N
SONY	STRD911	4	N	N
SONY	STRD915	4	N	N
SONY	STRDA30ES	4	N	Y
SONY	STRDA50ES	4	N	Y
SONY	STRDA80ES	4	N	Y
SONY	STRDA90ESG	4	N	Y
SONY	STRDE1015G	4	N	Y
SONY	STRDE305	4	N	Y
SONY	STRDE310	4	N	Y
SONY	STRDE315	4	N	Y
SONY	STRDE325	4	N	Y
SONY	STRDE405	4	N	Y
SONY	STRDE415	4	N	Y
SONY	STRDE425	4	N	Y
SONY	STRDE515	4	N	Y
SONY	STRDE605	4	N	N
SONY	STRDE615	4	N	Y
SONY	STRDE625	4	N	Y
SONY	STRDE705	4	N	Y
SONY	STRDE805G	4	N	N
SONY	STRDE815G	4	N	Y
SONY	STRDE905G	4	N	Y
SONY	STRDE915	4	N	Y
SONY	STRG1ES	4	N	N
SONY	STRG3	4	N	N
SONY	STRGA7ES	4	N	Y
SONY	STRGX40ES	4	N	N
SONY	STRGX47ES	4	N	N
SONY	STRGX67ES	4	N	N
SONY	STRGX69ES	4	N	N
SONY	STRGX700ES	4	N	N

SONY	STRGX7ESII	4	N	N
SONY	STRGX800ES	4	N	N
SONY	STRGX80ES	4	N	N
SONY	STRGX900ES	4	N	N
SONY	STRGX90ES	4	N	N
SONY	STS211	3	N	N
SONY	STS444	2	N	N
SONY	STS550ES	3	N	N
SONY	STS555ES	2	N	N
SONY	STS707ES	3	N	Y
SONY	STS730ES	3	N	N
SONY	STSA5ES	3	N	Y
SONY	STSE200	3	N	Y
SONY	SV T 3050	3	N	N
SONY	SVO1250	3	N	N
SONY	SVO1320	3	N	Y
SONY	SVO140	3	N	Y
SONY	SVO1410	3	N	Y
SONY	SVO1420	3	N	Y
SONY	SVO1450	3	N	Y
SONY	SVO150	3	N	Y
SONY	SVO1500	3	N	Y
SONY	SVO1520	3	N	Y
SONY	SVO1550	3	N	Y
SONY	SVO160	3	N	N
SONY	SVO1610	3	N	Y
SONY	SVO1620	3	N	Y
SONY	SVO1630	3	N	N
SONY	SVO2000	3	N	Y
SONY	SVO2100	3	N	N
SONY	SVO960	4	N	N
SONY	SVO9600	4	N	N
SONY	SVP1110A	3	N	Y
SONY	SVP120	3	N	N
SONY	SVP120	3	N	N
SONY	SVP1210	3	N	Y
SONY	SVT100	3	N	N
SONY	SVT3050	3	N	N
SONY	SX-1070	3	N	N
SONY	SX-M700	3	N	N
SONY	TAAE2000ESD	4	N	N
SONY	TAAV531	4	N	N
SONY	TAAV670	4	N	N
SONY	TADL100	3	N	N
SONY	TADM1000ES	3	N	Y
SONY	TAE1000ESD	4	N	N
SONY	TAE77ESD	3	N	N
SONY	TAE80ES	4	N	N
SONY	TAE9000ES	4	N	Y
SONY	TAF500ES	4	N	N
SONY	TAF606ES	4	N	N
SONY	TAF707ES	4	N	N

SONY	TAN110	3	N	N
SONY	TAN220	4	N	N
SONY	TAN55ES	4	N	N
SONY	TAN77ES	5	N	N
SONY	TAN80ES	5	N	N
SONY	TAN9000ES	5	N	Y
SONY	TCC5	4	N	N
SONY	TCFX120	3	N	N
SONY	TCFX160	3	N	N
SONY	TCFX170	3	N	N
SONY	TCFX211	3	N	N
SONY	TCFX505R	3	N	N
SONY	TCFX6C	3	N	N
SONY	TCK611S	3	N	N
SONY	TCK615S	3	N	N
SONY	TCK717ES	3	N	N
SONY	TCK890ES	4	N	N
SONY	TCKA1ES	3	N	N
SONY	TCKA1ESA	3	N	Y
SONY	TCKA2ES	3	N	Y
SONY	TCKA35	4	N	Y
SONY	TCKA3ES	4	N	Y
SONY	TCKE400S	3	N	Y
SONY	TCR302	3	N	N
SONY	TCR303	3	N	N
SONY	TCR503	3	N	N
SONY	TCRX370	3	N	N
SONY	TCRX420	3	N	N
SONY	TCRX470	3	N	N
SONY	TCRX606ES	3	N	N
SONY	TCRX70ES	3	N	N
SONY	TCRX77ES	3	N	N
SONY	TCRX79ES	3	N	N
SONY	TCW320	3	N	N
SONY	TCW345	3	N	Y
SONY	TCW365	3	N	N
SONY	TCW370	3	N	N
SONY	TCW435	3	N	N
SONY	TCWA7ES	3	N	N
SONY	TCWA7ESA	3	N	Y
SONY	TCWA8ES	3	N	N
SONY	TCWA8ESA	3	N	Y
SONY	TCWA9ES	4	N	Y
SONY	TCWE305	3	N	Y
SONY	TCWE405	3	N	Y
SONY	TCWE425	3	N	Y
SONY	TCWE605S	3	N	Y
SONY	TCWE625	3	N	Y
SONY	TCWE805	3	N	Y
SONY	TCWE805S	3	N	Y
SONY	TCWR10ES	3	N	N
SONY	TCWR11ES	4	N	N

SONY	TCWR350Z	3	N	Y
SONY	TCWR445	3	N	N
SONY	TCWR465	3	N	N
SONY	TCWR520	3	N	N
SONY	TCWR521	3	N	N
SONY	TCWR531	3	N	N
SONY	TCWR535	3	N	N
SONY	TCWR545	3	N	N
SONY	TCWR565	3	N	N
SONY	TCWR590	3	N	N
SONY	TCWR635S	3	N	N
SONY	TCWR645S	3	N	N
SONY	TCWR661	3	N	Y
SONY	TCWR665S	3	N	N
SONY	TCWR670	4	N	N
SONY	TCWR690	3	N	N
SONY	TCWR701ES	4	N	N
SONY	TCWR720	4	N	N
SONY	TCWR750	4	N	N
SONY	TCWR775	4	N	N
SONY	TCWR790	3	N	N
SONY	TCWR800	3	N	N
SONY	TCWR801ES	3	N	N
SONY	TCWR80ES	4	N	N
SONY	TCWR810	3	N	N
SONY	TCWR820	4	N	N
SONY	TCWR875	4	N	N
SONY	TCWR87ES	4	N	N
SONY	TCWR8ES	3	N	N
SONY	TCWR901ES	4	N	Y
SONY	TCWR90ES	4	N	N
SONY	TCWR930	4	N	N
SONY	TCWR950	4	N	N
SONY	TCWR97ES	4	N	N
SONY	TCWR99ES	4	N	Y
SONY	TTV8	2	N	N
SONY	TU1041U	2	N	N
SONY	TU1110	2	N	N
SONY	UP1200A	3	N	N
SONY	UP1200R	3	N	N
SONY	UP2100	3	N	Y
SONY	UP2200	3	N	Y
SONY	UPD7000	5	N	N
SONY	UVW1200	5	N	N
SONY	UVW1400	5	N	N
SONY	V8	2	N	N
SONY	VO7600	5	N	N
SONY	VO9600	5	N	N
SONY	VO9850	6	N	N
SONY	VP5000	6	N	N
SONY	VP5020	5	N	N
SONY	VP5040	5	N	N

SONY	VP7000	5	N	N
SONY	VP7020	5	N	N
SONY	VP7040	5	N	N
SONY	VP9000	5	N	N
SONY	VPR722	2	N	N
SONY	VTX1000	2	N	N
SONY	X303ES	3	N	N
SONY	YSW150	2	N	N
SOUNDOLIER	THPCXB	3	N	N
SOUNDOLIER	THUNDER PRO CXA	3	N	N
SOUNDSTREAM	C1	3	N	N
SOUNDSTREAM	C2	3	N	Y
SOUNDSTREAM	DA1	4	N	Y
SOUNDSTREAM	DA2	2	Y	N
SOUNDSTREAM	SN1	2	N	N
SOUNDSTREAM	SNX1	2	N	Y
SOUNDSTREAM	T1	3	N	Y
SOUNDSTREAM	TOUCH 1	3	N	Y
SPECO	SSB5	2	N	N
SQUARE D	EPLHDA1000	4	N	N
SQUARE D	EPLHDC1000	5	N	N
SQUARE D	EPLMDM1000	3	N	N
SSI	4000	3	N	N
SSI	4500	3	N	N
SSI	M360	2	N	N
STARGATE	ELITE PLUS	2	N	Y
STI	210A	4	N	Y
STI	MINITOWER	10	N	N
STRATA	STR1000	2	N	N
STUDIO SPEC	TU2	2	N	N
SUMO	0710	2	N	N
SUN	GDM1662B	10	N	Y
SUN	GDM17E10	10	N	Y
SUN	SPARKSTATION	2	N	N
SYLVANIA	MINITOWER	10	N	N
SYMPHONIC	7870	3	N	Y
SYMPHONIC	SV421E	3	N	Y
TANDBERG	3001A	3	N	N
TANDBERG	3006A	3	N	N
TANDBERG	3016A	6	N	N
TANDBERG	3018A	3	N	N
TASCAM	102	3	N	N
TASCAM	103	3	N	N
TASCAM	112R	3	N	N
TASCAM	202	4	N	N
TASCAM	202WR	3	N	N
TASCAM	225	3	N	N
TASCAM	CD601	4	N	N
TATUNG	CM17MKR	9	N	Y
TEAC	124	4	N	N
TEAC	3340S	12	N	N
TEAC	A103	4	N	N

TEAC	AD3	4	N	N
TEAC	AD4	3	N	N
TEAC	AD500	4	N	N
TEAC	AG360	4	N	N
TEAC	AG750	3	N	N
TEAC	AGV1020	4	N	N
TEAC	AVG1050	4	N	N
TEAC	CD100	3	N	N
TEAC	CDP1100	3	N	N
TEAC	CDP250	3	N	N
TEAC	CDP4500	3	N	N
TEAC	ED570	3	N	N
TEAC	EQA10	2	N	N
TEAC	M750R	4	N	N
TEAC	MB20	3	N	N
TEAC	PD11	3	N	N
TEAC	PD365	3	N	N
TEAC	PD410	3	N	N
TEAC	PD435	3	N	N
TEAC	PD480	3	N	N
TEAC	PD490	3	N	N
TEAC	PD500M	3	N	N
TEAC	PD600M	3	N	N
TEAC	PD800M	3	N	N
TEAC	PDD1260	3	N	Y
TEAC	PDD2200	3	N	Y
TEAC	PDD2400	3	N	N
TEAC	PDD700	3	N	N
TEAC	PDD850	3	N	N
TEAC	PDD880	3	N	N
TEAC	PDD900	3	N	N
TEAC	PDX100	5	N	N
TEAC	R400	3	N	N
TEAC	R425	3	N	N
TEAC	R435X	3	N	N
TEAC	R450	4	N	N
TEAC	R455CHX	3	N	N
TEAC	R540	4	N	N
TEAC	R550	4	N	N
TEAC	R560	4	N	N
TEAC	R616X	3	N	N
TEAC	R888XBL	3	N	N
TEAC	RST55R	3	N	N
TEAC	SLPJ1	3	N	N
TEAC	TR400	3	N	N
TEAC	TX4030	3	N	N
TEAC	V200	3	N	Y
TEAC	V210C	3	N	N
TEAC	V250	3	N	Y
TEAC	V270C	3	N	N
TEAC	V285CHX	3	N	N
TEAC	V3010	4	N	N

TEAC	V306	3	N	N
TEAC	V330	3	N	N
TEAC	V370	4	N	N
TEAC	V375	4	N	N
TEAC	V377	4	N	Y
TEAC	V437C	3	N	N
TEAC	V480	4	N	N
TEAC	V510	4	N	N
TEAC	V550X	3	N	N
TEAC	V9	3	N	N
TEAC	V909RX	3	N	N
TEAC	V970X	3	N	N
TEAC	W355	3	N	N
TEAC	W370C	3	N	N
TEAC	W420C	4	N	N
TEAC	W450R	4	N	N
TEAC	W460C	3	N	N
TEAC	W500C	3	N	N
TEAC	W518R	4	N	N
TEAC	W520R	4	N	N
TEAC	W525R	4	N	N
TEAC	W550R	4	N	N
TEAC	W580R	4	N	N
TEAC	W6000R	4	N	N
TEAC	W660R	3	N	N
TEAC	W700R	4	N	N
TEAC	W750R	4	N	N
TEAC	W760R	4	N	N
TEAC	W780R	4	N	N
TEAC	W790R	3	N	N
TEAC	W800R	4	N	N
TEAC	W850	4	N	N
TEAC	W850R	4	N	N
TEAC	W990	3	N	N
TEAC	W995RX	3	N	N
TEAC	Z5000	4	N	N
TEAC	Z7000	4	N	N
TECHNICS	M235	3	N	N
TECHNICS	M63	4	N	N
TECHNICS	RS780R	3	N	N
TECHNICS	RS907	3	N	N
TECHNICS	RS915	4	N	N
TECHNICS	RS917	3	N	N
TECHNICS	RS928R	3	N	N
TECHNICS	RS933W	3	N	N
TECHNICS	RSB105	3	N	N
TECHNICS	RSB11W	3	N	N
TECHNICS	RSB14	3	N	N
TECHNICS	RSB207	3	N	N
TECHNICS	RSB29R	3	N	N
TECHNICS	RSB50	3	N	N
TECHNICS	RSB605	3	N	N

TECHNICS	RSB78R	3	N	N
TECHNICS	RSB85	3	N	N
TECHNICS	RSB905	3	N	N
TECHNICS	RSB965	4	N	N
TECHNICS	RSBR465	3	N	N
TECHNICS	RSD510W	3	N	N
TECHNICS	RSDC10	4	N	N
TECHNICS	RSM222	3	N	N
TECHNICS	RSM224	3	N	N
TECHNICS	RST130	3	N	N
TECHNICS	RST20	3	N	N
TECHNICS	RST22	3	N	N
TECHNICS	RST230	3	N	N
TECHNICS	RST55R	3	N	N
TECHNICS	RST60R	3	N	N
TECHNICS	RST80R	3	N	N
TECHNICS	RSTR155	4	N	N
TECHNICS	RSTR165	4	N	N
TECHNICS	RSTR210	4	N	N
TECHNICS	RSTR232	4	N	N
TECHNICS	RSTR255	4	N	N
TECHNICS	RSTR272	4	N	Y
TECHNICS	RSTR313	4	N	N
TECHNICS	RSTR333	4	N	N
TECHNICS	RSTR355	4	N	N
TECHNICS	RSTR373	4	N	N
TECHNICS	RSTR555	4	N	N
TECHNICS	RSTR575	4	N	N
TECHNICS	RSTR777	4	N	N
TECHNICS	RSTR979	4	N	N
TECHNICS	SA222	4	N	N
TECHNICS	SA350	3	N	N
TECHNICS	SAAX6	4	N	Y
TECHNICS	SAEX110	4	N	Y
TECHNICS	SAEX300	4	N	Y
TECHNICS	SAEX320	4	N	Y
TECHNICS	SAEX410	4	N	Y
TECHNICS	SAGX130	3	N	N
TECHNICS	SAGX170	4	N	N
TECHNICS	SAGX190	4	N	N
TECHNICS	SAGX290	4	N	Y
TECHNICS	SAGX300	3	N	N
TECHNICS	SAGX650	4	N	N
TECHNICS	SETX100	4	N	N
TECHNICS	SH8017	2	N	N
TECHNICS	SH8066	3	N	N
TECHNICS	SHAC500D	2	N	Y
TECHNICS	SHAV44	3	N	N
TECHNICS	SHZ210	3	N	N
TECHNICS	SLMC400	4	N	Y
TECHNICS	SLMC50	4	N	Y
TECHNICS	SLMC60	4	N	Y

TECHNICS	SLMC700	5	N	N
TECHNICS	SLP101	3	N	N
TECHNICS	SLP102	3	N	N
TECHNICS	SLP110	2	N	N
TECHNICS	SLP170	3	N	N
TECHNICS	SLP2	3	N	Y
TECHNICS	SLP220	2	N	N
TECHNICS	SLP222	3	N	N
TECHNICS	SLP250	3	N	N
TECHNICS	SLP300	2	N	N
TECHNICS	SLP300C	3	N	N
TECHNICS	SLP320	2	N	N
TECHNICS	SLP350	3	N	N
TECHNICS	SLP370	3	N	N
TECHNICS	SLP500	3	N	N
TECHNICS	SLP520	3	N	N
TECHNICS	SLP555	3	N	N
TECHNICS	SLP600C	3	N	N
TECHNICS	SLP720	3	N	N
TECHNICS	SLP770	3	N	N
TECHNICS	SLP800C	3	N	N
TECHNICS	SLP999	4	N	N
TECHNICS	SLPC30	3	N	N
TECHNICS	SLPC33	3	N	Y
TECHNICS	SLPD1010	3	N	N
TECHNICS	SLPD647	4	N	N
TECHNICS	SLPD788	3	N	N
TECHNICS	SLPD807	3	N	N
TECHNICS	SLPD825	4	N	N
TECHNICS	SLPD827	4	N	N
TECHNICS	SLPD867	3	N	N
TECHNICS	SLPD887	3	N	N
TECHNICS	SLPD888	3	N	N
TECHNICS	SLPD927	4	N	N
TECHNICS	SLPD947	4	N	N
TECHNICS	SLPD987	3	N	N
TECHNICS	SLPG100	3	N	N
TECHNICS	SLPG300	3	N	N
TECHNICS	SLPG340	3	N	N
TECHNICS	SLPG440	3	N	N
TECHNICS	SLPG450	3	N	N
TECHNICS	SLPJ1	3	N	N
TECHNICS	SLPS50	3	N	N
TECHNICS	SLPS70	4	N	N
TECHNICS	SLPS840	3	N	N
TECHNICS	SLPS900	4	N	N
TECHNICS	ST7300	4	N	N
TECHNICS	STG40	2	N	N
TECHNICS	STG450	2	N	N
TECHNICS	STG46	2	N	N
TECHNICS	STG50	2	N	N
TECHNICS	STG6T	2	N	N

TECHNICS	STG7	3	N	N
TECHNICS	STK50	2	N	N
TECHNICS	STZ410	2	N	N
TECHNICS	SU760	3	N	N
TECHNICS	SUA6MK2	3	N	N
TECHNICS	SUG91	4	N	N
TECHNICS	SUV660	4	N	N
TECHNICS	SUV6X	4	N	N
TECHNICS	SUZ610	3	N	N
TECHNOVISION	PC2	2	N	Y
TEKTRONIX	119-5132-10	10	N	Y
TEKTRONIX	1700F00	4	N	N
TEKTRONIX	1740	4	N	N
TEKTRONIX	2205	4	N	N
TEKTRONIX	7603	7	N	Y
TEKTRONIX	CMC250	2	N	N
TEKTRONIX	TXD1734R	10	N	Y
TEKTRONIX	WVR500	2	N	N
TELEBYTE	101871	3	N	Y
TELEBYTE	JV419NT	2	N	N
TELECATION	4000	2	N	N
TELECATION	VR100	2	N	N
TELERATE	MD12	7	N	Y
TELEVIDEO	9065	9	N	Y
TELEX	T2X	3	N	N
TELOS	ZEPHYR EXPRESS	3	N	Y
THOMPSON	CM36512V1	8	N	Y
THRESHOLD	FET1	2	N	Y
TICE	AVA	4	N	Y
TMK	2053	4	N	N
TOA	900	3	N	N
TOA	A512A	3	N	N
TOA	A901A	3	N	N
TOA	A903A	3	N	N
TOA	A906A	4	N	N
TOA	BG10	3	N	N
TOA	SM25A	4	N	Y
TONE COMM.	NT1U220TC	2	N	N
TOSHIBA	CF13H22	8	N	Y
TOSHIBA	DX800	3	N	N
TOSHIBA	F482	3	N	Y
TOSHIBA	KV6300A	3	N	N
TOSHIBA	KV7024A	3	N	Y
TOSHIBA	M2330	3	N	N
TOSHIBA	M4200	3	N	N
TOSHIBA	M441	3	N	Y
TOSHIBA	M450	3	N	Y
TOSHIBA	M462	3	N	Y
TOSHIBA	M5800	3	N	N
TOSHIBA	M622	3	N	Y
TOSHIBA	M631	3	N	N
TOSHIBA	M641	3	N	N

TOSHIBA	M647	3	N	Y
TOSHIBA	M648	3	N	N
TOSHIBA	M651	3	N	Y
TOSHIBA	M658	3	N	Y
TOSHIBA	M661	3	N	Y
TOSHIBA	M662	3	N	Y
TOSHIBA	M672	3	N	N
TOSHIBA	M683	3	N	Y
TOSHIBA	M751	3	N	Y
TOSHIBA	M752	3	N	Y
TOSHIBA	M754	8	N	Y
TOSHIBA	M754	3	N	N
TOSHIBA	M760	3	N	Y
TOSHIBA	M761	3	N	Y
TOSHIBA	M769	3	N	Y
TOSHIBA	M781	3	N	Y
TOSHIBA	M782	3	N	Y
TOSHIBA	M784	3	N	Y
TOSHIBA	MP200	3	N	N
TOSHIBA	PCG50R	3	N	N
TOSHIBA	SD2008U	2	N	N
TOSHIBA	SD2107U	2	N	N
TOSHIBA	SD2108	2	N	N
TOSHIBA	SD3006	2	N	N
TOSHIBA	SD3107U	2	N	N
TOSHIBA	SD3108U	2	N	N
TOSHIBA	SV771	3	N	N
TOSHIBA	SV970	3	N	N
TOSHIBA	TRX120	3	N	N
TOSHIBA	TRX1820	3	N	N
TOSHIBA	TRX2000	3	N	N
TOSHIBA	TSR202	2	N	N
TOSHIBA	V87MS	3	N	N
TOSHIBA	VX445	3	N	N
TOSHIBA	XR9037	3	N	N
TOSHIBA	Z70K	3	N	N
TOUCH	CAD14RG	8	N	Y
TRIMBLE	GALAXY SENTINAL	7	N	N
TRIPPLITE	BCPRO675	6	N	Y
TRIPPLITE	PR7B	3	N	N
TV-LINK	EXEC.DIRECTOR	3	N	N
TV-LINK	MODEL 20	2	N	N
UHF ASSOCIATES	TV2000	2	N	N
ULTRX	RDR31	3	N	N
UNIDEN	BC760	2	N	N
UNIDEN	BC9000XLT	3	N	Y
UNIDEN	LTD715	2	N	Y
UNIDEN	PC4000	3	N	Y
UNIDEN	SQ590	3	N	N
UNIDEN	UDS200	3	N	N
UNIDEN	UST4200	3	N	Y
UNIDEN	UST4400	3	N	Y

UNIDEN	UST4500	3	N	N
UNIDEN	UST7700	2	N	N
UNIDEN	UST9900	2	N	N
UNITY MOTION	HDR1000	2	N	Y
US ROBOTICS	SPORTSTER 14,400	2	N	Y
US ROBOTICS	SPORTSTER 28,800	2	N	Y
US ROBOTICS	V EVERTHING	2	N	N
VECTOR RESEARCH	VCD420R	3	N	N
VECTOR RESEARCH	VCD610R	3	N	N
VECTOR RESEARCH	VCX450	3	N	N
VELODYNE	CROSSOVERBYPAS	2	N	N
VELODYNE	ULD	3	N	N
VELODYNE	ULD12	2	N	N
VELODYNE	ULD15	3	N	N
VELODYNE	ULD18	3	N	N
VERMIL VENTURES	VKA280	4	N	N
VERTEX	FTL 7011/99	2	N	Y
VICON	V113APT B1	2	N	N
VICON	V270SP	3	N	N
VICON	VM613	9	N	Y
VIDEO CIPHER	2100E	3	N	N
VIDEO CIPHER	UST4200	3	N	N
VIDEO SHOW	150	2	N	N
VIDEO SHOW	HARDDISK	2	N	Y
VIDEO SHOW	HQ	2	N	Y
VIDEOLINK	1600U	4	Y	N
VIDEOLINK	AV420R	2	N	N
VIDEOLINK	AV426	2	N	N
VIDEOLOGIC	MEDIATOR	2	N	N
VIDEONICS	TM3000	2	N	N
VIDEOTEK	AVM13S	8	N	Y
VIDEOTEK	RM8A	6	N	N
VIDEOTEK	TSM51	4	N	Y
VIDICRAFT	AUDVIDENHACE	2	N	N
VIDICRAFT	AVS100	2	N	N
VIDICRAFT	DETAILER111	2	N	N
VIDICRAFT	DETAILERIV	2	N	N
VIDIKRON	LD40	2	N	N
VIDIKRON	VP20	2	N	N
VIDTECH	RS2001	2	N	N
VIEW SONIC	14ES	8	N	Y
VIEW SONIC	15ES	9	N	Y
VIEW SONIC	15GA	9	N	Y
VIEW SONIC	G771	9	N	Y
VIEW SONIC	GA655	9	N	Y
VIEW SONIC	P655	8	N	Y
VIEW SONIC	VCDTS21366	10	N	N
VISION TECHNOLOGY	VC1	2	N	Y
VOCOPRO	KC100	2	N	N
VSP LABS	HPF102	2	N	N
VUESCAN	TV86	2	N	N
WABER	DATAGUARD	2	N	N

WADIA	9DECODER	2	N	N
WADIA	9PWR.SUPPLY	2	N	N
WEGENER COMM.	199501	2	N	Y
WEGENER COMM.	DVR95	2	N	N
WESTLIGHT	BX35XENON	2	N	Y
WOLLENSAK	8050A	3	N	N
WYSE	530-04	8	N	Y
WYSE	75	8	N	N
WYSE	WY30	7	N	N
WYSE	WY55	8	N	Y
WYSE	WY60	8	N	Y
YAESU	FT900AT	3	N	Y
YAESU	G450XL	5	N	Y
YAMAHA		3	N	N
YAMAHA	AVC50	3	N	N
YAMAHA	AVC70	3	N	N
YAMAHA	AVS700	3	N	N
YAMAHA	AVX500	3	N	N
YAMAHA	AVX700	4	N	N
YAMAHA	AX400U	4	N	N
YAMAHA	AX490	4	N	N
YAMAHA	AX500U	4	N	N
YAMAHA	AX570	4	N	N
YAMAHA	C45	3	N	N
YAMAHA	CD2000	3	N	N
YAMAHA	CD28	3	N	N
YAMAHA	CD29	3	N	N
YAMAHA	CD3	3	N	N
YAMAHA	CD450	3	N	N
YAMAHA	CD46	3	N	N
YAMAHA	CD700	3	N	N
YAMAHA	CDC500U	3	N	N
YAMAHA	CDC555	3	N	N
YAMAHA	CDC605	3	N	N
YAMAHA	CDC610U	3	N	N
YAMAHA	CDC615	3	N	N
YAMAHA	CDC625	3	N	N
YAMAHA	CDC635	3	N	N
YAMAHA	CDC645	3	N	N
YAMAHA	CDC655	3	N	N
YAMAHA	CDC665	3	N	N
YAMAHA	CDC705	3	N	N
YAMAHA	CDC715	3	N	N
YAMAHA	CDC735	3	N	N
YAMAHA	CDC755	3	N	N
YAMAHA	CDC765	3	N	N
YAMAHA	CDC805	3	N	N
YAMAHA	CDC815	3	N	N
YAMAHA	CDC835	3	N	N
YAMAHA	CDC845	3	N	N
YAMAHA	CDC96	3	N	N
YAMAHA	CDM900	5	N	N

YAMAHA	CDV1000	3	N	N
YAMAHA	CDV1100	3	N	N
YAMAHA	CDV1700	4	N	N
YAMAHA	CDVW901	4	N	N
YAMAHA	CDX1050	3	N	N
YAMAHA	CDX1100U	3	N	N
YAMAHA	CDX2	3	N	N
YAMAHA	CDX390	3	N	N
YAMAHA	CDX410U	3	N	N
YAMAHA	CDX480	3	N	N
YAMAHA	CDX500U	3	N	N
YAMAHA	CDX510U	3	N	N
YAMAHA	CDX520	3	N	N
YAMAHA	CDX530	3	N	N
YAMAHA	CDX550	3	N	N
YAMAHA	CDX5U	2	N	N
YAMAHA	CDX930	3	N	N
YAMAHA	CX1000U	4	N	N
YAMAHA	CX2	2	N	N
YAMAHA	CX600U	3	N	N
YAMAHA	CX630	3	N	N
YAMAHA	DDP1	3	N	N
YAMAHA	DDP2	3	N	N
YAMAHA	DSP1	2	N	N
YAMAHA	DSP100	2	N	N
YAMAHA	DSP3000	3	N	N
YAMAHA	DSPA1	5	N	N
YAMAHA	DSPA1000	4	N	N
YAMAHA	DSPA2070	4	N	N
YAMAHA	DSPA3090	4	N	N
YAMAHA	DSPA700	4	N	N
YAMAHA	DSPA780	4	N	N
YAMAHA	DSPA970	4	N	N
YAMAHA	DSPE1000	4	N	N
YAMAHA	DSPE200	4	N	N
YAMAHA	DSPE300	4	N	N
YAMAHA	DSPE390	3	N	N
YAMAHA	DSR100	2	N	N
YAMAHA	DSR70PRO	2	N	N
YAMAHA	DVD1000	3	N	N
YAMAHA	DVDS700	3	N	N
YAMAHA	EQ1100U	3	N	N
YAMAHA	EQ500U	3	N	N
YAMAHA	EQ550	3	N	N
YAMAHA	EQ630	3	N	N
YAMAHA	EQ70	3	N	N
YAMAHA	K1020	4	N	N
YAMAHA	K142	4	N	N
YAMAHA	K30	3	N	N
YAMAHA	K420	3	N	N
YAMAHA	K540	3	N	N
YAMAHA	K640	3	N	Y

YAMAHA	K65	3	N	N
YAMAHA	K700	3	N	N
YAMAHA	KX1200U	4	N	N
YAMAHA	KX200U	3	N	N
YAMAHA	KX230	3	N	N
YAMAHA	KX250	3	N	N
YAMAHA	KX300U	3	N	N
YAMAHA	KX330	3	N	N
YAMAHA	KX360	4	N	N
YAMAHA	KX400U	3	N	N
YAMAHA	KX500U	3	N	N
YAMAHA	KX530	3	N	N
YAMAHA	KX690	3	N	N
YAMAHA	KXR430	3	N	N
YAMAHA	KXR470	4	N	N
YAMAHA	KXR700U	3	N	Y
YAMAHA	KXR730	3	N	N
YAMAHA	KXW202U	3	N	N
YAMAHA	KXW262	4	N	N
YAMAHA	KXW282	3	N	N
YAMAHA	KXW302U	3	N	N
YAMAHA	KXW332	3	N	N
YAMAHA	KXW362	4	N	N
YAMAHA	KXW382	3	N	N
YAMAHA	KXW392	4	N	N
YAMAHA	KXW492	4	N	N
YAMAHA	KXW500U	3	N	N
YAMAHA	KXW582	3	N	N
YAMAHA	KXW602	3	N	N
YAMAHA	KXW900U	4	N	N
YAMAHA	KXW952	4	N	N
YAMAHA	M35	3	N	N
YAMAHA	M45	4	N	N
YAMAHA	MS101	6	N	Y
YAMAHA	MX1000U	4	N	N
YAMAHA	MX2	3	N	N
YAMAHA	MX35	3	N	N
YAMAHA	MX6000U	4	N	N
YAMAHA	MX600U	4	N	N
YAMAHA	MX630	5	N	N
YAMAHA	MXM70	4	N	N
YAMAHA	R7	3	N	N
YAMAHA	RX1100U	4	N	N
YAMAHA	RX1130	4	N	N
YAMAHA	RX350	4	N	N
YAMAHA	RX496	4	N	N
YAMAHA	RX550	4	N	N
YAMAHA	RX595	4	N	N
YAMAHA	RX700U	3	N	N
YAMAHA	RX730	3	N	N
YAMAHA	RX750	4	N	N
YAMAHA	RX770	4	N	N

YAMAHA	RX930	4	N	N
YAMAHA	RX950	5	N	N
YAMAHA	RXV1050	5	N	N
YAMAHA	RXV2090	5	N	N
YAMAHA	RXV2092	5	N	N
YAMAHA	RXV490	4	N	N
YAMAHA	RXV590	4	N	N
YAMAHA	RXV850	5	N	N
YAMAHA	RXV870	5	N	N
YAMAHA	RXV890	5	N	N
YAMAHA	RXV990	5	N	N
YAMAHA	RXV992	5	N	N
YAMAHA	SR50	2	N	N
YAMAHA	T17	2	N	N
YAMAHA	T32	2	N	N
YAMAHA	T520	2	N	N
YAMAHA	T85	3	N	N
YAMAHA	TC920B	4	N	N
YAMAHA	TX1000U	3	N	N
YAMAHA	TX350	2	N	N
YAMAHA	TX400U	2	N	N
YAMAHA	TX470	3	N	N
YAMAHA	TX480	3	N	N
YAMAHA	TX492	3	N	N
YAMAHA	TX500U	3	N	N
YAMAHA	TX540	2	N	N
YAMAHA	TX930	2	N	N
YAMAHA	TX950	2	N	N
YAMAHA	YV1000	3	N	N
YAMAHA	YV1110S	3	N	N
YAMAHA	YV800	3	N	N
ZENITH	243166	2	N	N
ZENITH	CV510	2	N	N
ZENITH	D1314W	9	N	Y
ZENITH	DVX2100	3	N	N
ZENITH	E0930S	6	N	N
ZENITH	EE3131(ST1622	2	N	Y
ZENITH	J0920X	7	N	Y
ZENITH	J0930Y	7	N	Y
ZENITH	SJ1325W	9	N	Y
ZENITH	SLO953X	6	N	Y
ZENITH	SLS1323S	9	N	Y
ZENITH	ST1082	3	N	Y
ZENITH	SY13245	8	N	Y
ZENITH	VIP	2	N	Y
ZENITH	VR3000	3	N	N
ZENITH	VR3100	3	N	Y
ZENITH	VR4127	3	N	Y
ZENITH	VRE200	3	N	N
ZENITH	VRF300HF	3	N	N
ZENITH	VRG180	3	N	N
ZENITH	VRJ420HF	3	N	Y

ZENITH	VRL4130	3	N	Y
ZENITH	VRL4132	3	N	Y
ZENITH	VRM4120	3	N	Y
ZERCOM	MAXZ	3	N	N