



MSA Music Style Disks

MSA-501/502/503 Music Style Disks

What's the MSA-501/502/503? From Ragtime to Rap, these new MSA Series Music Style Disks offer a wide assortment of world beats and styles. Each disk has been configured by converting 32 styles carefully selected from the MSD series.

Compatible Models

KR-370, KR-570, KR-770, KR-1070, AT-30, AT-90, G-600, G-800, G-1000, E-66, E-86, E-96, E-500, RA-95, RA-800

MSA-501 Around the World 1

- | | |
|-------------|-----------------|
| 01 Rock 1 | 17 Boogie 1 |
| 02 Rock 2 | 18 Rock'N'Roll |
| 03 Rap | 19 Twist |
| 04 House 1 | 20 Charleston |
| 05 Dance 1 | 21 Slow Rock 1 |
| 06 Funk 1 | 22 Slow Rock 2 |
| 07 Funk 2 | 23 Ballad 1 |
| 08 Fusion 1 | 24 Ballad 2 |
| 09 8Beat 1 | 25 Slow Swing 1 |
| 10 8Beat 2 | 26 Slow Swing 2 |
| 11 8Beat 3 | 27 Swing 1 |
| 12 8Beat 4 | 28 Foxtrot |
| 13 16Beat 1 | 29 Big Band |
| 14 16Beat 2 | 30 Shuffle |
| 15 16Beat 3 | 31 Swing Waltz |
| 16 16Beat 4 | 32 Dixie |

MSA-503 Around the World 3

- | | |
|-------------|--------------------|
| 01 8Beat 5 | 17 Blues 2 |
| 02 8Beat 6 | 18 Blues 3 |
| 03 8Beat 7 | 19 R&B |
| 04 8Beat 8 | 20 Swing 2 |
| 05 16Beat 5 | 21 Swing 3 |
| 06 16Beat 6 | 22 5/4 |
| 07 16Beat 7 | 23 Country 2 |
| 08 16Beat 8 | 24 Country Waltz 2 |
| 09 Rock 3 | 25 Waltz 2 |
| 10 Rock 4 | 26 Polka 2 |
| 11 Funk 3 | 27 Raggae 3 |
| 12 Funk 4 | 28 Bossa Nova 2 |
| 13 Funk 5 | 29 Rhumba 2 |
| 14 House 2 | 30 Latin 2 |
| 15 Dance 2 | 31 Merengue |
| 16 Fusion 2 | 32 Meneaito |

MSA-502 Around the World 2

- | | |
|-----------------|--------------------|
| 01 Bossa Nova 1 | 17 Slow Waltz 1 |
| 02 Samba 1 | 18 Slow Waltz 2 |
| 03 Samba 2 | 19 Waltz 1 |
| 04 Latin 1 | 20 March |
| 05 Salsa | 21 Polka 1 |
| 06 Chacha | 22 Baroque |
| 07 Rhumba | 23 Country 1 |
| 08 Mambo 1 | 24 Country Waltz 1 |
| 09 Mambo 2 | 25 Blues 1 |
| 10 Tango | 26 Slow Swing 3 |
| 11 Beguine | 27 Boogie 2 |
| 12 Raggae 1 | 28 Ragtime |
| 13 Raggae 2 | 29 Standard |
| 14 Lambada | 30 Ballad 3 |
| 15 Son | 31 M'Town |
| 16 Caribbean | 32 Mexican Rock |



MSD Music Style Disks

Music Style Disks For E-66/E-86/E-96/G-600/G-800/G-1000/RA-95/RA-800

The MSD Series of Music Style Disk are specially designed for use with the E-66/E-86/E-96/G-600/G-800/G-1000/RA-95/RA-800 to provide a broader selection of music styles. Each 3.5" floppy disk contains 16 styles are comprehensive, covering blues to samba and swing as well as many other international styles. The MSD Series allows you to enjoy realtime performance taking advantage of the Arranger function along with complete eight-part accompaniments. These styles can be edited on an E-86, E-96, G-800 or RA-800.

Around the World 1 (MSD-102)

- Blues • Slow Swing • Boogie 2 • Ragtime • Lambada
- Son • Samba 2 • Mambo • Slow Waltz • Standard
- Ballad 3 • Reggae 2 • Caribbean • M'Town
- Mexican Rock • Country Waltz

Around the World 2 (MSD-103)

- Rock 1 • Rock 2 • Rap • House • Dance • Funk 1 • Funk 2 • Fusion • 8 Beat 1 • 8 Beat 2 • 8 Beat 3 • 8 Beat 4
- 16 Beat 1 • 16 Beat 2 • 16 Beat 3 • 16 Beat 4

Around the World 3 (MSC-104)

- Boogie • Rock'n • Twist • Charlest • Slow Rock 1
- Slow Rock 2 • Ballad 1 • Ballad 2 • Slow Swing 1
- Slow Swing 2 • Swing • Foxtrot • Big Band • Shuffle
- Swing Waltz • Dixie

Around World 4 (MSD-105)

- Bossa • Samba • Latin • Salsa • Chacha • Rhumba
- Mambo • Tango • Slow Waltz • Waltz • March • Polka
- Baroque • Country • Beguine • Reggae

Around World 5 (MSD-106)

- Rock 1 • Rock 2 • Funk 1 • Funk 2 • 8 Beat 1 • 8 Beat 2
- 16 Beat 1 • 16 Beat 2 • Reggae • Swing • Country
- Waltz 2 • Polka • Bossa • Rhumba • Fusion

American and Piano Collection (MSD-107)

- Rock 3 • Rock 4 • Funk 4 • R&B • Gospel • Big Band
- Modern Ballad • Jazz Waltz • Pop Piano 1 • Pop Piano 2
- Contemporary • 50's Ballad • Ballad Shuffle • Swing Pop
- Jazz Piano • Slow Waltz 3

Around the World 6 (MSC-108)

- 8 Beat 5 • 8 Beat 6 • 16 Beat 5 • 16 Beat 6 • House 2
- Dance 10 • Funk 3 • Blues 2 • Blues 3 • R&B 2 • Swing 2
- 5/4 • Latin 2 • Merengue 2 • Meneaito • C'Waltz 3