

No.	Style	CC#0	CC#32	No.	Style	CC#0	CC#32	Division	PC#
11	ROCK1	1	5	51	BOSSA	22	3	Original Basic	2
12	ROCK2	1	6	52	SAMBA	27	3	Original Advanced	3
13	RAP	33	1	53	LATIN	22	4	Variation Basic	9
14	HOUSE	2	3	54	SALSA	25	1	Variation Advanced	10
15	DANCE	2	4	55	CHACHA	24	1		
16	FUNK1	3	3	56	RHUMBA	23	1	Intro Basic	65
17	FUNK2	3	4	57	MAMBO	38	1	Intro Advanced	66
18	FUSION	28	1	58	TANGO	26	2	Ending Basic	73
								Ending Advanced	74
21	8BEAT1	6	3	61	SL WALTZ	18	2		
22	8BEAT2	6	4	62	WALTZ	17	5	Fill to Original Basic	89
23	8BEAT3	6	5	63	MARCH	20	2	Fill to Original Advanced	90
24	8BEAT4	6	6	64	POLKA	19	3	Fill to Variation Basic	97
25	16BEAT1	7	4	65	BAROQUE	21	1	Fill to Variation Advanced	98
26	16BEAT2	7	5	66	COUNTRY	16	2	Break Mute	113
27	16BEAT3	7	6	67	BEGUINE	39	2		
28	16BEAT4	7	7	68	REGGAE	8	3	Fill to Variation*	81
								Fill to Original*	82
31	BOOGIE	9	2	71	PDOBLE	40	0	Intro*	83
32	ROCK'N	10	3	72	KARS	47	0	Ending*	84
33	TWIST	10	4	73	ANADOLU	48	0	Break Mute*	85
34	CHARLEST	11	2	74	ARAB	49	0		
35	SL ROCK1	5	3	75	MALFOUF	50	0		
36	SL ROCK2	5	4	76	KERONCNG	51	0		
37	BALLAD1	4	3	77	TROT	52	0		
38	BALLAD2	4	4	78	ENKA	41	4		
41	SLSWING1	13	1		Card Style 1	112	0		
42	SLSWING2	13	2		Card Style 2	112	1		
43	SWING	12	2		Card Style 3	112	2		
44	FOXTROT	34	1		Card Style 4	112	3		
45	BIG BAND	14	1		Card Style 5	112	4		
46	SHUFFLE	15	2		Card Style 6	112	5		
47	SW WALTZ	17	6		Card Style 7	112	6		
48	DIXIE	11	1		Card Style 8	112	7		

* E-Series Compatible