

No.	Style	CC#0	CC#32	No.	Style	CC#0	CC#32	Division	PC#
11	ROCK1	1	9	51	BOSSA1	22	7	Original Basic	2
12	ROCK2	1	10	52	BOSSA2	22	8	Original Advanced	3
13	RAP	33	2	53	LATIN	22	9	Variation Basic	9
14	HOUSE	2	13	54	CHACHA	24	3	Variation Advanced	10
15	TECHNO	2	14	55	RHUMBA	23	3		
16	DANCE	2	15	56	POPROCK	39	6	Intro Basic	65
17	FUNK1	3	6	57	BEGUINE	39	7	Intro Advanced	66
18	FUNK2	3	7	58	TANGO	26	4	Ending Basic	73
								Ending Advanced	74
21	8BEAT1	6	9	61	SAMBA1	27	6		
22	8BEAT2	6	10	62	SAMBA2	27	7	Fill to Original Basic	89
23	8BEAT3	6	11	63	SALSA	25	2	Fill to Original Advanced	90
24	8BEAT4	6	12	64	MAMBO1	38	3	Fill to Variation Basic	97
25	16BEAT1	7	10	65	MAMB02	38	4	Fill to Variation Advanced	98
26	16BEAT2	7	11	66	CALYPSO	35	2	Break Mute	113
27	16BEAT3	7	12	67	REGGAE	8	4		
28	16BEAT4	7	13	68	FUSION	28	2	Fill to Variation*	81
								Fill to Original*	82
31	BOOGIE	9	3	71	SL WALTZ	18	5	Intro*	83
32	ROCK'N1	10	12	72	SW WALTZ	17	11	Ending*	84
33	ROCK'N2	10	13	73	WALTZ	17	12	Break Mute*	85
34	TWIST	10	14	74	MARCH	20	5		
35	SL ROCK1	5	7	75	FOXTROT	34	3		
36	SL ROCK2	5	8	76	POLKA	19	6		
37	BALLAD1	4	8	77	BAROQUE	21	2		
38	BALLAD2	4	9	78	COUNTRY	16	5		
41	SLSWING1	13	5		U1 User Style	120	0		
42	SLSWING2	13	6		U2 User Style	120	1		
43	BLUES	44	3		U3 User Style	120	2		
44	SWING	12	5		U4 User Style	120	3		
45	BIG BAND	14	3		U5 User Style	120	4		
46	SHUFFLE	15	3		U6 User Style	120	5		
47	DIXIE	11	3		U7 User Style	120	6		
48	CHARLEST	11	4		U8 User Style	120	7		

\* E-Series Compatible